



Operating instructions

IO-Link master with EtherCAT interface

DataLine

8 ports

IP 65 / IP 66 / IP 67

AL1332

Firmware: 3.1.x

English

Contents

1	Preliminary note	5
1.1	Legal and copyright information	5
1.2	Purpose of the document	5
1.3	Explanation of Symbols	5
1.4	Change history	6
2	Safety instructions	7
2.1	General	7
2.2	Required background knowledge	7
2.3	Safety symbols on the device	7
2.4	IT security	8
3	Intended use	9
4	Function	10
4.1	Communication, parameter setting, evaluation	11
4.1.1	IO-Link	11
4.1.2	EtherCAT	11
4.1.3	Internet of Things (IoT)	11
4.1.4	Security mode	11
4.1.5	Parameter setting	12
4.1.6	Visual indication	12
4.2	Digital inputs	12
4.3	IO-Link supply	12
5	Mounting	13
5.1	Mount the device	13
6	Electrical connection	14
6.1	Notes	14
6.2	Connecting the EtherCAT ports	15
6.3	Connecting the IoT port	15
6.4	IO-Link ports	16
6.4.1	Connecting IO-Link devices for Class A operation	16
6.4.2	Connecting IO-Link devices for Class B operation	17
6.5	Connecting the device	18
7	Operating and display elements	19
7.1	Overview	19
7.2	LED indicators	20
7.2.1	Status LEDs	20
7.2.2	EtherCAT interface	21
7.2.3	IoT port	21
7.2.4	Voltage supply	21
7.2.5	IO-Link Ports (Class A)	22

8	Set-up	23
9	Configuration	24
9.1	LR DEVICE	25
9.1.1	Remarks	26
9.1.2	IoT: Configure IP settings	26
9.1.3	IoT: Configure security mode	27
9.1.4	IoT: Configuring access rights	28
9.1.5	IoT: Configure the interface to LR AGENT or LR SMARTOBSERVER	29
9.1.6	Fieldbus: Configure EtherCAT interface	29
9.1.7	IO-Link ports: Activate data transfer to LR AGENT or LR SMARTOBSERVER	30
9.1.8	IO-Link ports: Configure operating mode	31
9.1.9	IO-Link ports: Set the device validation and data storage	32
9.1.10	Info: Show device information	33
9.1.11	Firmware: Reset device to factory settings	33
9.1.12	Firmware: Reboot the device	33
9.1.13	Configure IO-Link devices	34
9.2	ifm IoT Core	35
9.2.1	Programmers' notes	36
9.2.2	First steps	41
9.2.3	General functions	41
9.2.4	IoT: Configuring access rights	46
9.2.5	IoT: Configuring IP settings	46
9.2.6	IoT: Configuring security mode	47
9.2.7	Fieldbus: Configuring the fieldbus interface	50
9.2.8	IO-Link ports: Setting the operating mode of pin 4 (US)	50
9.2.9	IO-Link ports: Configuring device validation and data storage	51
9.2.10	IO-Link ports: Configuring data transfer to LR AGENT or LR SMARTOBSERVER	53
9.2.11	IO-Link ports: Reading / writing process data	53
9.2.12	IO-Link ports: Indicating port events	56
9.2.13	IO-Link devices: Accessing parameters	56
9.2.14	IO-Link devices: Reading an writing device information	58
9.2.15	IO-Link devices: Indicating IO-Link events	58
9.2.16	Gateway: Resetting, rebooting and localising the device	58
9.2.17	Gateway: Reading device information	59
9.2.18	Gateway: Reading status and diagnostic information	59
9.2.19	Gateway: Updating the firmware	60
9.2.20	Gateway: Setting the application tag	61
9.2.21	Subscribing to notifications	62
9.2.22	Using Web Socket	66
9.2.23	MQTT support	68
9.2.24	Using the IoT-Core Visualizer	72
9.3	EtherCAT	79
9.3.1	Install ESI file	79
9.3.2	Integrate the IO-Link master into the TwinCAT project	79
9.3.3	Configure IO-Link master	80
9.3.4	Configure IO-Link ports	80
9.3.5	Configure cyclic process data	80
9.3.6	Read and write cyclic process data	81
9.3.7	Read diagnostic and status information	82
9.3.8	Read IO-Link events	82
9.3.9	Configure IO-Link devices	83
9.3.10	EtherCAT: Programmers' notes	84

10	Operation	86
10.1	Using web-based management	86
11	Maintenance, repair and disposal	87
11.1	Cleaning process	87
11.2	Updating the firmware	87
11.3	Replacing IO-Link device	87
12	Factory settings	88
13	Accessories	89
14	Appendix	90
14.1	Technical data	91
14.1.1	Application	91
14.1.2	Electrical data	91
14.1.3	Inputs / outputs	91
14.1.4	Inputs	92
14.1.5	Outputs	92
14.1.6	Interfaces	92
14.1.7	Operating conditions	93
14.1.8	Approvals / tests	93
14.1.9	Mechanical data	93
14.1.10	Electrical connection	94
14.2	EtherCAT	95
14.2.1	Parameter data	96
14.2.2	Cyclic data	97
14.2.3	Acyclic data	98
14.2.4	Events	107
14.3	ifm IoT Core	111
14.3.1	Overview: IoT profile	112
14.3.2	Overview: IoT types	119
14.3.3	Overview: IoT services	120
15	Index	135

1 Preliminary note

Content

Legal and copyright information	5
Purpose of the document	5
Explanation of Symbols	5
Change history	6

33203

1.1 Legal and copyright information

33117

© All rights reserved by ifm electronic gmbh. No part of this manual may be reproduced and used without the consent of ifm electronic gmbh.

All product names, pictures, companies or other brands used on our pages are the property of the respective rights owners:

- AS-i is the property of the AS-International Association, (→ www.as-interface.net)
- CAN is the property of the CiA (CAN in Automation e.V.), Germany (→ www.can-cia.org)
- CODESYS™ is the property of the CODESYS GmbH, Germany (→ www.codesys.com)
- DeviceNet™ is the property of the ODVA™ (Open DeviceNet Vendor Association), USA (→ www.odva.org)
- EtherNet/IP® is the property of the → ODVA™
- EtherCAT® is a registered trade mark and patented technology, licensed by Beckhoff Automation GmbH, Germany
- IO-Link® is the property of the → PROFIBUS Nutzerorganisation e.V., Germany (→ www.io-link.com)
- ISOBUS is the property of the AEF – Agricultural Industry Electronics Foundation e.V., Deutschland (→ www.aef-online.org)
- Microsoft® is the property of the Microsoft Corporation, USA (→ www.microsoft.com)
- Modbus® is the property of the Schneider Electric SE, France (→ www.schneider-electric.com)
- PROFIBUS® is the property of the PROFIBUS Nutzerorganisation e.V., Germany (→ www.profibus.com)
- PROFINET® is the property of the → PROFIBUS Nutzerorganisation e.V., Germany
- Windows® is the property of the → Microsoft Corporation, USA

1.2 Purpose of the document

34227

This document is only for device types "IO-Link master - EtherCAT gateway (DataLine) 8 port IP 65 / IP 66 / IP 67" (art. no.: AL1332).

It is part of the device and contains information about the correct handling of the product.

- ▶ Read this document before using the device.
- ▶ Keep this document during the service life of the device.

1.3 Explanation of Symbols

34171



WARNING

Warning of serious personal injury.
Death or serious irreversible injuries may result.



CAUTION

Warning of personal injury.
Slight reversible injuries may result.



NOTICE

Warning of damage to property



Important note
Non-compliance can result in malfunction or interference



Information
Supplementary note



Request for action



Reaction, result



"see"

abc

Cross-reference

123

Decimal number

0x123

Hexadecimal number

0b010

Binary number

[...]

Designation of pushbuttons, buttons or indications

1.4 Change history

61145

Version	Topic	Date
00	New creation of the document	04 / 2019
01	Correction: Technical data - current rating per output	09 / 2019
02	<ul style="list-style-type: none"> ▪ Added: New IoT core functions ▪ Added: IoT Core Visualizer ▪ Correction: Description of the IoT Core Service getssubscriptioninfo 	10 / 2020

2 Safety instructions

Content

General	7
Required background knowledge	7
Safety symbols on the device	7
IT security	8

28333

2.1 General

58525

- The device described is a subcomponent for integration into a system. The manufacturer is responsible for the safety of the system. The system manufacturer undertakes to perform a risk assessment and to create documentation in accordance with legal and normative requirements to be provided to the operator and user of the system. This documentation must contain all necessary information and safety instructions for the operator, the user and, if applicable, for any service personnel authorised by the manufacturer of the system.
- Read this document before setting up the product and keep it during the entire service life.
- The product must be suitable for the corresponding applications and environmental conditions without any restrictions.
- Only use the product for its intended purpose (→ **Intended use** (→ S. 9)).
- If the operating instructions or the technical data are not adhered to, personal injury and/or damage to property may occur.
- The manufacturer assumes no liability or warranty for any consequences caused by tampering with the product or incorrect use by the operator.
- Installation, electrical connection, set-up, programming, configuration, operation and maintenance of the product must be carried out by personnel qualified and authorised for the respective activity.
- Protect units and cables against damage.

2.2 Required background knowledge

34185

This document is intended for specialists. Specialists are people who, based on their relevant training and experience, are capable of identifying risks and avoiding potential hazards that may be caused during operation or maintenance of the product.

The document contains information about the correct handling of the product.

2.3 Safety symbols on the device

34199



General warning

Observe instructions in chapter "Electrical connection" (→ **Electrical connection** (→ S. 14))!

2.4 IT security

54678

NOTICE!

If the device is operated in an unprotected network environment.

- > Unauthorised read or write access to data is possible.
- > Unauthorised manipulation of the device function is possible.
- ▶ Check and restrict access options to the device:
 - Restrict access to authorised persons.
 - Do not connect the device to open networks or the internet.

If access from the internet is inevitable:

- ▶ choose a safe method to connect with the device (e. g. VPN).
- ▶ Use encrypted data transmission (e. g. https / TLS).

3 Intended use

58283

The device may only be used for the following purposes:

- as IO-Link master for configuration, administration and operation of IO-Link devices
- as gateway between IO-Link devices and AS-i network

The device is designed for use without a control cabinet in plant construction.

- ▶ Only use the device within the limits of the technical data (→ **Technical data** (→ S. [91](#))).

4 Function

Content

Communication, parameter setting, evaluation	11
Digital inputs	12
IO-Link supply.....	12

33836

4.1 Communication, parameter setting, evaluation

Content

IO-Link	11
EtherCAT	11
Internet of Things (IoT)	11
Security mode.....	11
Parameter setting	12
Visual indication.....	12

33860

4.1.1 IO-Link

34084

The device offers the following IO-Link functions:

- IO-Link master (IO-Link revision 1.0 and 1.1)
- 8 IO-Link ports for connection of IO-Link devices
- Provision of process data of the connected IO-Link devices for LR SMARTOBSERVER monitoring software (→ www.ifm.com)

4.1.2 EtherCAT

33676

The device offers the following EtherCAT functions:

- Provision of the functions of a EtherCAT Slave
- 2 port switch for access to the EtherCAT interface (X21/X22)
- Gateway for transmission of the process and parameter data between the connected IO-Link devices and the higher-level EtherCAT controller

4.1.3 Internet of Things (IoT)

54679

The device offers the following IoT functions:

- Gateway for the transmission of process, parameter and monitoring data between IO-Linkmaster / IO-Link devices and the IT network level
- REST-API to access process and parameter data
- Supported protocols: TCP/IP JSON, MQTT

4.1.4 Security mode

54697

The IoT interface offers the following optional security functions:

- Secure data transfer via encrypted connection (Secure Layer Transport - TLS)
- Access protection via authentication

4.1.5 Parameter setting

34210

The device provides the following configuration options:

- Parameter setting of the IO-Link master of the AL1332 with LR DEVICE parameter setting software, EtherCAT projection software or ifm IoT-Core services.
- Parameter setting of the connected IO-Link devices (sensors, actuators) with LR DEVICE parameter setting software, EtherCAT projection software or ifm IoT-Core services
- Storage of parameter sets of the connected IO-Link devices for automatic recovery (data storage)

4.1.6 Visual indication

34192

The device has the following visual indicators:

- Status and error indication of the gateway, of the EtherCAT connection and of the system
- Status display of the voltage supply
- Status and activity display of the Ethernet connection
- Status, error and short circuit/overload indication of the IO-Link ports

4.2 Digital inputs

33817

The device has 8 additional digital inputs (type 2 according to EN 61131-2).

The digital inputs are on pin 2 of the ports X01...X04.

All inputs refer to the potential of the device supply (pin 3).

4.3 IO-Link supply

34077

The device has 8 supplies for IO-Link devices.

The IO-Link ports X01...X08 are ports class A.

Every supply provides short circuit monitoring.

The device ensures fire protection for the connected IO-Link devices by providing a power-restricted circuit at the IO-Link ports (according to IEC61010-1 and Class 2 according to UL1310).

5 Mounting

Content

Mount the device	13
------------------------	----

34058

5.1 Mount the device

34059



- ▶ Disconnect the system from power before installation.
 - ▶ For installation choose a flat mounting surface.
 - ▶ Please observe the maximum tightening torque.
-
- ▶ Fix the unit to the mounting surface using 2 M5 mounting screws and washers.
 - Tightening torque: 1.8 Nm
 - ▶ Ground the unit via the two mounting screws of the upper mounting lugs.

6 Electrical connection

Content

Notes	14
Connecting the EtherCAT ports	15
Connecting the IoT port	15
IO-Link ports	15
Connecting the device	18

33805

6.1 Notes

51957



A qualified electrician must connect the unit.

- ▶ The national and international regulations setting up electrical equipment must be complied with.

The unit is only suitable for operation using SELV/PELV voltages.

- ▶ Please note the information concerning IO-Link wiring!

This unit contains components that may be damaged or destroyed by electrostatic discharge (ESD).

- ▶ Please observe the required precautions against electrostatic discharge!

The M12 connection parts in the device comply with the ingress resistance requirements of the standard EN 61076-2-101. To adhere to the protection rating, only cables certified to this standard must be used. The system creators undertake to ensure ingress resistance for cables which they cut to length themselves.

- ▶ Carry out the fitting according to the indications of the cable manufacturer. A maximum of 0.8 Nm is permitted.
- ▶ During installation, place the M12 connector vertically so that the coupling nut will not damage the thread.
- ▶ Depending on the mounting conditions, cables must be provided with a strain relief to avoid unacceptable loads on the mounting points and M12 connections.
- ▶ Make sure that the M12 connection parts are correctly seated and mounted correctly. The specified protection rating can not be guaranteed if this is not observed.

For UL applications:

- ▶ To connect the IO-Link master and the IO-Link devices, only use UL-certified cables of the CYJV or PVVA category with a minimum temperature of 80 °C (75 °C in case of maximum ambient temperature of 40 °C).

Wiring: → **Technical data** (→ S. [91](#))

By means of basic insulation according to EN61010-1, the circuits are separated from each other and from device surfaces that could be touched (secondary circuit with 30 V DC maximum, supplied from mains circuit up to 300 V overvoltage category II).

By means of basic insulation according to EN61010-1, the communication interfaces are separated from each other and from device surfaces that could be touched (secondary circuit with 30 V DC maximum, supplied from mains circuit up to 300 V overvoltage category II). They are designed for network environment 0 according to IEC TR62102.

6.2 Connecting the EtherCAT ports


33671



- ▶ Connect the device via the M12 socket X21 and/or X22 to the EtherCAT network (e.g. EtherCAT PLC, additional EtherCAT device)
- ▶ To connect the devices, use M12 connectors with protection rating IP 65 / IP 66 / IP 67 or higher (→ **Accessories** (→ S. [89](#))).
- ▶ Cover the unused sockets with M12 protective caps (art no. E73004).

6.3 Connecting the IoT port

34044



- ▶ Connect the device via the M12 socket X23 to the IT network (e.g. laptop/PC with LR DEVICE parameter setting software, laptop/PC with LR SMARTOBSERVER monitoring software, laptop/PC with software capable of processing http requests).
- ▶ To connect the devices, use M12 connectors with protection rating IP 65 / IP 66 / IP 67 or higher (→ **Accessories** (→ S. [89](#))).
- ▶ Cover the unused sockets with M12 protective caps (art no. E73004)

6.4 IO-Link ports

51958

The IO-Link ports of the AL1332 meet the requirements of the IO-Link specifications 1.0 to 1.1.2.


- ▶ Please note the information concerning IO-Link wiring!
- ▶ Cover unused sockets with M12 protective caps (art. no.: E73004).

6.4.1 Connecting IO-Link devices for Class A operation

51959

Wiring information:

- The connected IO-Link devices must be supplied exclusively via the IO-Link master.
- The additional digital inputs IO-Link ports X01...X08 (pin 2) have a type 2 behaviour according to the standard EN61131-2. The connected electronics must be electrically suited for this.



- ▶ Connect the connectors of the IO-Link devices with the M12 sockets of the IO-Link ports X01...X08.
 - Maximum cable length per IO-Link port: 20 m
- ▶ To connect the devices, use M12 connectors with protection rating IP 65 / IP 66 / IP 67 or higher (→ **Accessories** (→ S. [89](#))).

6.4.2 Connecting IO-Link devices for Class B operation

51960

Notes on wiring:

- For Class B operation, the IO-Link device must be supplied with an additional auxiliary voltage UA using a Y connection cable.




WARNING

Non-compliance with the electrical separation of the circuits

- > Risk of fire!
 - ▶ Ensure that the external supply UA is galvanically separated from the circuit of the IO-Link Master by assuring basic insulation (according to IEC 61010-1, secondary circuit with 30 V DC maximum, supplied from mains circuit up to 300 V of overvoltage category II).
 - ▶ Ensure that the IO-Link devices and the connection technology support the galvanic separation.



In case of operation as port class B, the additional digital input of the IO-Link port (pin 2) is not available!



- ▶ Connect the connectors of the IO-Link devices via a Y connection cable with the M12 sockets of the IO-Link ports X01...X08.
- ▶ Connect the Y cable to 24 V DC (20...30 V SELV/PELV)
- ▶ To connect the devices, use M12 connectors with protection rating IP 65 / IP 66 / IP 67 or higher (→ **Accessories** (→ S. [89](#)))!

6.5 Connecting the device

33882



- ▶ Disconnect power.
- ▶ Connect the IO-Link Master via M12 socket X31 to 24 V DC (20...30 V SELV/PELV; according to EN61010-1, secondary circuit with maximum 30 V DC supplied by mains circuit up to 300 V of overvoltage category II).
 - Maximum cable length: 25 m
- ▶ To connect the device, use M12 connectors with protection rating IP 65 / IP 66 / IP 67 or higher (→ **Accessories** (→ S. [89](#))).



When using cable length greater than 25 m keep in mind the voltage drop as well as the required minimum voltage supply of 20 V!

7 Operating and display elements


Content

Overview.....	19
LED indicators	20

34063

7.1 Overview

34052



- ① RDY, RUN and ERR status LEDs
→ **Status LEDs** (→ S. [20](#))
- ② Status LEDs L/A of the EtherCAT interfaces 1 (X21) and 2 (X22)
→ **EtherCAT interface** (→ S. [21](#))
- ③ LNK, ACT status-LEDs and IoT LED of the IoT interface (X23)
→ **IoT port** (→ S. [21](#))
- ④ IOL and DI status-LEDs of the IO-Link port (X01...X08)
→ **IO-Link Ports (Class A)** (→ S. [22](#))
- ⑤ US status LED of the voltage supply (X31)
→ **Voltage supply** (→ S. [21](#))

7.2 LED indicators

34047

The device only has the following LED indicators:

7.2.1 Status LEDs

34198

The RDY LED indicates the status of the gateway.

The RUN LED indicates the current state of the EtherCAT state machine.

The ERR LED indicates occurring errors.

Status LED			Description
RDY	green	on	Status: OK
		flashes 5 Hz	Status: Error
		flashes (200 ms on, 800 ms off)	Status: Firmware update is running
		off	Status: Gateway not running or gateway booting
RUN	green	on	Device in OPERATIONAL state
		flashes 2.5 Hz	Device in PRE-OPERATIONAL state
		flashes (200 ms on, 1000 ms off)	Device in SAFE-OPERATIONAL state
		flashes 10 Hz	Device is booting and not yet in INIT state or device is in BOOTSRAP state
		off	Device in INIT state
ERR	red	on	Error in application controller
		flashes 10 Hz	Boot error
		flashes (200 ms on, 200 ms off, 200 ms on, 1000 ms off)	Watchdog error (EtherCAT or process data)
		flashes (200 ms on, 1000 ms off)	Local error
		flashes 2.5 Hz	Invalid configuration
		off	No error

7.2.2 EtherCAT interface

33682

Each EtherCAT interface (X21, X22) has 1 L/A LED. The LED indicates the status of the Ethernet connection.

Status LED			Description
L/A	green	on	Ethernet connection established
		flashes	Data is transmitted via the Ethernet interface.
		off	No Ethernet connection

7.2.3 IoT port

34043

The IoT port has the 3 LNK, ACT and IoT LEDs. The LEDs indicate the status of the Ethernet connection and the device identification.

Status LED			Description
LNK	green	on	Ethernet connection established
		off	No Ethernet connection
ACT	yellow	flashes	Data is transmitted via the Ethernet interface.
		off	No data transmission
IoT	green	flashes	Device identification active

7.2.4 Voltage supply

34191

The interface for voltage supply (X31) has the LED that is marked as US. The LED indicates the status of the voltage supply.

Status LED			Description
US	green	on	The supply voltage U_s is applied.
		off	No supply voltage is applied or the applied supply voltage is too low.

7.2.5 IO-Link Ports (Class A)

34074

Each IO-Link Port Class A has 2 LEDs labelled IOL and DI. The LEDs indicate the status of the IO-Link port.

Status LED		Description	
IOL	yellow	Off	Port configured as DI/DO: pin 4 (C/Q) = OFF
		on	Port configured as DI/DO: pin 4 (C/Q) =ON
	green	flashing 1 Hz	Port configured asIO-Link: no IO-Link device found
		Flashing with 2 Hz	Port configured asIO-Link: Status PREOPERATE
		on	Port configured asIO-Link: Status OPERATE
	red	Flashing with 2 Hz	Port configuration error or short circuit / overload on US
		on	Transmission Error
DI	yellow	Off	Digital input: pin 2 = OFF
		on	Digital input: pin 2 = ON

8 Set-up

52811

When the supply voltage is switched on, the AL1332 starts with the factory settings. The display elements signal the current operating mode (→ **Operating and display elements** (→ S. [19](#))).

To enable parameter setting of the AL1332, the IoT interface and / or the fieldbus interface must be configured according to the network environment.

- ▶ Configure fieldbus interface (→ **Fieldbus: Configuring the fieldbus interface** (→ S. [50](#), **"Integrate the IO-Link master into the TwinCAT project"** → S. [79](#))).
- ▶ Configure IoT interface (LR DEVICE: → **IoT: Configure IP settings** (→ S. [26](#)) or → **IoT: Configuring IP settings** (→ S. [46](#))).
- > IoT / fieldbus interface has valid settings.
- > User can set the parameters of the AL1332.

Further steps:

- Optional: Update firmware of AL1332 (→ **Updating the firmware** (→ S. [87](#))).
- Set the parameters of the AL1332 (→ **Configuration** (→ S. [24](#))).

9 Configuration

Content	
LR DEVICE	25
ifm IoT Core	35
EtherCAT	79

33858

9.1 LR DEVICE

Content

Remarks	26
IoT: Configure IP settings	26
IoT: Configure security mode	27
IoT: Configuring access rights	28
IoT: Configure the interface to LR AGENT or LR SMARTOBSERVER	29
Fieldbus: Configure EtherCAT interface.....	29
IO-Link ports: Activate data transfer to LR AGENT or LR SMARTOBSERVER	30
IO-Link ports: Configure operating mode	31
IO-Link ports: Set the device validation and data storage.....	32
Info: Show device information	33
Firmware: Reset device to factory settings	33
Firmware: Reboot the device.....	33
Configure IO-Link devices	34

33692

On delivery, the AL1332 is configured with the factory settings (→ **Factory settings** (→ S. [88](#))).

Required software: LR DEVICE (1.5.0.x or higher) (art.-no.: QA0011/QA0012)

9.1.1 Remarks

Content

Offline parameter setting	26
Fail-safe values of the IO-Link ports.....	26

34180

Offline parameter setting

34060

The AL1332 supports the offline parameter setting. In this context, the user creates and stores a configuration for the IO-Link master and the connected IO-Link devices without being connected to the AL1332 (OFFLINE mode). The configuration created in this way can be stored as a file (*.lrp) and loaded to the AL1332 and activated at a later date.



Further information about offline parameter setting: → Operating instructions LR DEVICE

Fail-safe values of the IO-Link ports

52521



The AL1332 has no failsafe function for the outputs of the IO-Link ports. If the fieldbus connection is interrupted, the last used output values are written and marked as invalid.

9.1.2 IoT: Configure IP settings

34049

For access to the IO-Link master via the IT infrastructure the user has to set the IP settings of the IoT port.



To configure the IP settings with DHCP, a DHCP server has to be active in the IT network. If no DHCP server can be reached in the IT network, an IP address is automatically assigned to the IoT port with the Zeroconfig protocol (address range: → **Factory settings** (→ S. [88](#))).

To configure the IP settings of the IoT interface:

- ▶ Select [IoT] menu.
- > The menu page shows the current settings.
- ▶ Set the following parameters as required:

Name	Description	Possible values	
[DHCP]	Activate/deactivate the DHCP client of the device	[Static IP]	IP settings were set by the user
		[DHCP]	IP settings are set by a DHCP server in the network.
[IP address]*	IP address of the IoT port	Factory setting: 169.254.X.X	
[Subnet mask]*	Subnet mask of the Ethernet network	Factory setting: 255.255.0.0	
[Default gateway IP address]*	IP address of the network gateway	Factory setting: 0.0.0.0	
[MAC address]	MAC address of the IoT port	The value is firmly set.	

* ... can only be edited if parameter [DHCP] = [Static IP]

- ▶ Save changed values on the device.

9.1.3 IoT: Configure security mode

The IoT interface of the IO-Link offers a security mode. It enables secure data transmission via transport encryption and restriction of the access to IO-Link masters and IO-Link devices via user authentication.

To configure the security mode:

- ▶ Select [IoT] menu.
- > The menu page shows the current settings.
- ▶ Set the following parameters as required:

Name	Description	Possible values	
[Security mode HTTPS]	Set the security mode	[Disabled]	Security mode disabled
		[Enabled]	Security mode enabled
[Security password]	Password Note: The set password is not displayed.		

- ▶ Save changed values on the device.



The security mode only protects the access to the device via the IoT interface.
The user name "administrator" cannot be changed.



The security mode can be enabled without setting the password. During the attempt to write to the device, LR DEVICE requires to enter and confirm the password.

After entering the password, the user has unrestricted access to IO-Link masters and connected IO-Link devices. The password will only be requested again if the current LR DEVICE session is over (e. g. after restarting the LR DEVICE).

To change the set password:

- ▶ Sign in with a valid password.
- ▶ Enter the new password in the field [Security password].
- ▶ Write changes to the device.
- > The new password is set.

9.1.4 IoT: Configuring access rights

The access rights define which instance may read and / or write the parameter data, process data and event/diagnostic messages.

In order to configure the access rights to the IO-Link master:

- ▶ Select [IoT] menu.
- > The menu page shows the current settings.
- ▶ Set the following parameters as required:

Name	Description	Possible values	
[Access Rights]	The access rights to the parameter data, process data and the event/diagnostic messages of the IO-Link master as well as the connected IO-Link devices	[EtherCAT + IoT]*	<ul style="list-style-type: none"> ▪ EtherCAT and IoT Core have read and write access rights to parameters and process data ▪ EtherCAT and IoT Core have read access rights to events/alarms
		[EtherCAT + IoT (read-only)]	<ul style="list-style-type: none"> ▪ EtherCAT has read and write access rights to parameters and process data ▪ EtherCAT has read access rights to events/alarms ▪ IoT Core only has read access rights to parameters, process data and events/alarms
		[IoT only]	<ul style="list-style-type: none"> ▪ IoT Core has read and write access rights to parameters and process data ▪ IoT has read access rights to events/alarms ▪ EtherCAT has no access rights

* ... Factory setting

- ▶ Save changed values on the device.



If in LR DEVICE and EtherCAT projection software the parameter [Access Rights] is = [EtherCAT + IoT], the parameter values set in the EtherCAT projection software will always apply.

If the parameter [Access Rights] in LR DEVICE is = [IoT only], set the parameter [Access Rights] = [Keep settings] in the EtherCAT projection software.

If the parameter [Access Rights] in LR DEVICE is = [<Fieldbus> + IoT (read-only)], write access to the device configuration via LR DEVICE and IoT core services is blocked. To enable write access again, set the parameter to [<Fieldbus> + IoT] via fieldbus configuration software.

Changes of the parameter [Access Rights] will only be effective after restarting the IO-Link master (→ **Firmware: Reboot the device** (→ S. [33](#))).

9.1.5 IoT: Configure the interface to LR AGENT or LR SMARTOBSERVER

34048

To enable transfer of process data from the IO-Link master to LR AGENT or LR SMARTOBSERVER, the interface has to be configured accordingly.

- ▶ Select [IoT] menu.
- > The menu page shows the current settings.
- ▶ Set the following parameters as required:

Name	Description	Possible values	
[IP address LR Agent or SMARTOBSERVER]	IP address of LR AGENT or LR SMARTOBSERVER	Factory setting: 255.255.255.255	
[Port LR Agent or SMARTOBSERVER]	Port number that is used to send process data to LR AGENT or LR SMARTOBSERVER	0 ... 65535	Factory setting: 35100
[Interval LR Agent or SMARTOBSERVER]	Cycle time for the transfer of the process data to LR AGENT or LR SMARTOBSERVER (value in milliseconds)	[Off]	no transfer
		500 ... 2147483647	500 ms ... 2147483647 ms
[Application Tag]	Source identifier of the IO-Link master in the structure of LR AGENT or LR SMARTOBSERVER (String32)	Factory setting: AL1332	



After changing the parameter [Port LR Agent or SMARTOBSERVER] or [Application Tag], it may take 120 seconds before the device establishes a new TCP connection.

To prevent the delay:

- ▶ Reboot the device after changing the the parameter.
- ▶ Save changed values on the device.

9.1.6 Fieldbus: Configure EtherCAT interface

33828

The user can assign a name for the identification of the IO-Link master in the EtherCAT projection software.



The address of the EtherCAT port is assigned via the EtherCAT projection software.

To configure the fieldbus port:

- ▶ Select [Fieldbus] menu.
- > The menu page shows the current settings.
- > Set the following parameters as required:

Parameter	Description	Possible values
[Hostname]	Name of the device in the EtherCAT network	e.g. al1xxx
[MAC address]	MAC address of the device	The value is firmly set.

- ▶ Save changed values on the device.

9.1.7 IO-Link ports: Activate data transfer to LR AGENT or LR SMARTOBSERVER

33690

The user can decide separately for each IO-Link port whether the process data of the connected IO-Link devices should be transferred to LR AGENT or LR SMARTOBSERVER.



To transfer process data the interface to the LR AGENT or LR SMARTOBSERVER has to be correctly configured (→ **IoT: Configure the interface to LR AGENT or LR SMARTOBSERVER** (→ S. [29](#))).

To activate / deactivate data transfer:

- ▶ Select [Port x] menu (x = 1..8).
- > The menu page shows the current settings.
- ▶ Set the following parameters as required:

Name	Description	Possible values	
[Transmission to LR Agent or SMARTOBSERVER]	Transfer of process data of the connected IO-Link device to LR AGENT oder LR SMARTOBSERVER	[Disabled]	Transfer process data
		[Enabled]	Don't transfer process data

- ▶ Save changed values on the device.

9.1.8 IO-Link ports: Configure operating mode

The IO-Link ports X01...X08 of the device support the following operating modes:

- Disabled: no data transfer at pin 4 (C/Q) of the IO-Link port
- Digital input (DI): binary input signal at pin 4 (C/Q) of the IO-Link port
- Digital output (DO): binary output signal at pin 4 (C/Q) of the IO-Link port
- IO-Link: IO-Link data transfer via pin 4 (C/Q) of the IO-Link port

The user can set the operating mode separately for each IO-Link port.

To set the operating mode of an IO-Link port:

- ▶ Select [Port x] menu (x = 1...8).
- > The menu page shows the current settings.
- ▶ Set the following parameters as required:

Name	Description	Possible values	
[Mode Pin4 US]	Operating mode of pin 4 of the IO-Link port	[Disabled]	Port deactivated
		[DI]	Operation as digital input
		[DO]	Operation as digital output
		[IO-Link]	Operation as IO-Link interface
[Cycle time actual]**	Current cycle time of the data transfer between IO-Link master and IO-Link device on the port (value in microseconds)	Parameter can only be read	
[Cycle time preset]*	Cycle time of the data transfer between the IO-Link master and the IO-Link device at the port (value in microseconds)	0	The device automatically sets the fastest possible cycle time.
		1	1 microsecond
	
		132800	132800 microseconds
[Bitrate]**	Current transmission rate of the data transfer between the IO-Link master and the IO-Link device on the port	Parameter can only be read	

* ... Parameter only available if [Mode] = [IO-Link]

** ... Parameter only visible if the IO-Link device is connected to the IO-Link port.

- ▶ Save changed values on the device.

9.1.9 IO-Link ports: Set the device validation and data storage

33697

The user can choose how the IO-Link ports are to behave with regard to the device validation and the storage / recovery of parameter data of the connected IO-Link device.

The following options are available:

Option	Validation of the IO-Link device	Storage of the parameter values	Recovery of the parameter values
[No check and clear]	no	no	no
[Type compatible V1.0 device]	yes, test the compatibility with IO-Link standard V1.0	no	no
[Type compatible V1.1 device]	yes, test the compatibility with IO-Link standard V1.1	no	no
[Type compatible V1.1 device with Backup + Restore]	yes, test the compatibility with IO-Link standard V1.1 and identity of design (vendor ID and device ID)	yes, automatic storage of the parameter values; changes of the current parameter values will be stored	yes, recovery of the parameter values when connecting an identical IO-Link device with factory settings
[Type compatible V1.1 device with Restore]	yes, test the compatibility with IO-Link standard V1.1 and identity of design (vendor ID and device ID)	no, there is no automatic storage changes of the current parameter values will not be stored	yes, recovery of the parameter values when connecting an identical IO-Link device with factory settings



The options only apply if the IO-Link port is in the operating mode "IO-Link".

For options [Type compatible V1.1 device with Backup + Restore] and [Type compatible V1.1 device with Restore]: If the vendor ID and device ID are changed in the online mode, the data memory will be deleted and a new backup of the parameter values of the connected IO-Link device will be created in the IO-Link master.

To configure the device validation and the data storage:

- ▶ select [Port x] menu (x = 1...8).
- > The menu page shows the current settings.
- ▶ Set the following parameters as required:

Name	Description	Possible values	
[Validation / Data Storage]	Supported IO-Link standard and behaviour of the IO-Link master when connecting a new IO-Link device at port x (x = 1...8)	[No check and clear]	
		[Type compatible V1.0 device]	
		[Type compatible V1.1 device]	
		[Type compatible V1.1 device with Backup + Restore]	
		[Type compatible V1.1 device with Restore]	
[Vendor ID]	ID of the manufacturer that is to be validated	0...65535	Factory setting: 0# ifm electronic: 310
[Device ID]	ID of the IO-Link device that is to be validated	0...16777215	Factory setting: 0

- ▶ Save changed values on the device.

9.1.10 Info: Show device information

34065

To read the general information of the ifm IO-Link master:

- ▶ Select [Info] menu.
- > The menu page shows the current settings.

Name	Description	Possible values
[Product code]	Article number of the IO-Link master	AL1332
[Device family]	Device family of the IO-Link master	IO-Link master
[Vendor]	Vendor	ifm electronic gmbh
[SW-Revision]	Firmware of the IO-Link master	
[HW revision]	Hardware version of the IO-Link master	
[Bootloader revision]	Bootloader version of the IO-Link master	
[Serial number]	Serial number	

9.1.11 Firmware: Reset device to factory settings

33838

When the IO-Link master is reset, all parameters are set to the factory settings:

To reset the device to factory settings:

- ▶ Select [Firmware] menu.
- > The menu page shows the current settings.
- ▶ Click on [Factory Reset] to reset the device.
- > LR DEVICE sets the device to the factory settings.

9.1.12 Firmware: Reboot the device

33832

When rebooting the device, all settings are kept.

To restart the AL1332:

- ▶ Select [Firmware] menu.
- > The menu page shows the current settings.
- ▶ Click on [Reboot] to reboot the device.
- > LR DEVICE reboots the ifm IO-Link master.

9.1.13 Configure IO-Link devices

To configure the IO-Link devices connected to the device with the LR DEVICE parameter setting software:

Requirements:


- > IO-Link master is correctly installed and connected to the LR DEVICE parameter setting software.
- > The IO-Link device is connected correctly with the AL1332.
- > Operating mode of the IO-Link port is "IO-Link" (→ **IO-Link ports: Configure operating mode** (→ S. 31)).
- > IoT has write access rights to the IO-Link master (→ **IoT: Configuring access rights** (→ S. 28)).

1 Select IO-Link master

- ▶ Start LR DEVICE.
- ▶ Update IODD file library
OR:
Import IODD file of the IO-Link device manually.
- ▶ Scan network for devices.
- > LR DEVICE detects IO-Link master.

2 Add IO-Link device

- ▶ Under [ONLINE]: Click on the required IO-Link master.
- > LR DEVICE automatically detects the IO-Link devices connected to the IO-Link master (e.g. ifm sensor KG5065).



3 Configure IO-Link device

- ▶ Mouse click on the port to which the IO-Link device is connected.
- > LR DEVICE reads and shows the current parameter values of the IO-Link device.
- ▶ Configure IO-Link device.



Information about the available parameters of the IO-Link device: → IO Device Description (IODD) des IO-Link Devices

- ▶ Save the changed configuration on the IO-Link device.

9.2 ifm IoT Core

Content

Programmers' notes	36
First steps	41
General functions	41
IoT: Configuring access rights	46
IoT: Configuring IP settings	46
IoT: Configuring security mode	47
Fieldbus: Configuring the fieldbus interface	50
IO-Link ports: Setting the operating mode of pin 4 (US)	50
IO-Link ports: Configuring device validation and data storage.....	51
IO-Link ports: Configuring data transfer to LR AGENT or LR SMARTOBSERVER	53
IO-Link ports: Reading / writing process data	53
IO-Link ports: Indicating port events.....	56
IO-Link devices: Accessing parameters	56
IO-Link devices: Reading an writing device information	58
IO-Link devices: Indicating IO-Link events	58
Gateway: Resetting, rebooting and localising the device.....	58
Gateway: Reading device information.....	59
Gateway: Reading status and diagnostic information	59
Gateway: Updating the firmware	60
Gateway: Setting the application tag	61
Subscribing to notifications.....	62
Using Web Socket	66
MQTT support	68
Using the IoT-Core Visualizer.....	72

52244



General notes on the ifm IoT Core: → **Programmers' notes** (→ S. [36](#))

9.2.1 Programmers' notes

Content

IoT Core: General information	36
Access the ifm IoT Core	37
IoT Core: Diagnostic codes	40

34229

IoT Core: General information

52256

The DataLine device family has an IoT Core. The IoT Core allows the user to address the AL1332 from IT networks via a REST API and to integrate it into Internet-of-Things applications.

A device description is stored on the AL1332. This device description is a structured, machine-readable data object in JSON format. All current values of parameters, process data, diagnostic data and device information are mapped in this data object. These data values can be read and changed by means of services.

Access the ifm IoT Core

52257

The user can access the ifm IoT Core via HTTP requests. The following request methods are available.

GET request

33804

Using the GET method the user has read access to a data point.

The syntax of the request to the IoT Core is:

```
http://ip/datapoint/service
```

Parameter	Description
ip	IP address of the IoT interface
data_point	Data point which is to be accessed
service	Service

The syntax of the return of the IoT Core is:

```
{
  "cid":id,
  "data":{"value":resp_data},
  "code":diag_code
}
```

Parameter	Description
id	Correlation ID for the assignment of request and return
resp_data	Value of the data point; depending on the data type of the data point
diag_code	Diagnostic code (→ IoT Core: Diagnostic codes (→ S. 40))

Example: GET request

54033

Request (via browser):

```
http://192.168.0.250/devicetag/applicationtag/getdata
```

Response:

```
{
  "cid":-1,
  "data":{"value":"AL1332"},
  "code":200
}
```

POST request

54700

Using a POST request the user has read and write access to a data point.

The syntax of the request to the IoT Core is:

```
{
"code": "code_id",
"cid": id,
"adr": "data_point/service",
"data": {req_data},
"auth": {"user": "usr_id", "passwd": "password"}
}
```

Field	Parameter	Description	
code	code_id	Service class	
		▪ request	Request
		▪ transaction	Transaction
		▪ event	Event
cid	id	Correlation ID for the assignment of request and response; ID freely assignable by the user	
adr	data_point	Data point of the element tree which is to be accessed	
	service	Service to be performed (→ Overview: IoT services (→ S. 120))	
data*	req_data	Data to be transferred to the IoT Core (e.g. new values); syntax depending on the service	
auth**	usr_id	user name (base64 coded); default value: administrator	
	password	password (base64 coded)	

* = optional; only required for services, that submit data to the IoT core (e. g. setdata)

** = optional; only required, if security mode is activated

The syntax of the return of the IoT Core is:

```
{
"cid": id,
"data": {resp_data},
"code": diag_code
}
```

Field	Parameter	Description
cid	id	Correlation ID for the assignment of request and response (see request)
data*	resp_data	Value of the data point; syntax depending on the service
code	diag_code	Diagnostic code (→ IoT Core: Diagnostic codes (→ S. 40))

* = optional; only required for services, that receive data from the IoT core (e.g. getdata)

Example: POST request

54035

Request:

```
{
"code": "request",
"cid": 4711,
"adr": "devicetag/applicationtag/getdata"
}
```

Response:

```
{  
  "cid":4711,  
  "data":{"value":"AL1332"},  
  "code":200  
}
```

IoT Core: Diagnostic codes

54688

Code	Text	Description
200	OK	Request successfully processed
230	OK but needs reboot	Request successfully processed; IO-Link master must be restarted
231	OK but block request not finished	Request successfully processed; blockwise request, but not yet finished
232	Data has been accepted, but internally modified	New values have been accepted, but were adjusted by the IO-Link master (Master cycle time)
233	IP settings (of IoT-Port) have been updated. Application needs to reload device. Wait at least 1 second before reloading device.	IP settings have been successfully changed, IO-Link master will be reloaded; wait for at least 1 second
400	Bad request	Invalid request
401	Unauthorized	Non authorised request
403	Forbidden	Forbidden request
500	Internal Server Error	Internal fault
503	Service Unavailable	The service is not available (e. g. IO-Link port in wrong operating mode; no IO-Link device at IO-Link port)
530	The requested data is invalid	Invalid process data
531	IO-Link error	Error in IO-Link Master / device
532	PLC connected Error	Error while setting data, because IO-Link master is still connected to fieldbus PLC

9.2.2 First steps

52245

To read the device description of the AL1332:

- ▶ Send the following POST request to the AL1332:

```
{"code":"request","cid":-1,"adr":"gettree"}
```
- > AL1332 returns the device description as structured JSON object.
- ▶ Identify all substructures and the data points contained therein in the tree structure of the JSON object.
- ▶ Identify the applicable services for the access to substructures and the data points contained therein.

9.2.3 General functions

61148

The AL1332 has the type device (→ **Overview: IoT types** (→ S. [119](#))).

The following services can be used on the root element of the type device:

Service	Description
../gettree	Provide the complete tree or subtree of the device description (JSON)
../getidentity	Reading device information
../getdatamulti	Reading several parameter values sequentially
../getelementinfo	Reading detailed information of an element
../getsubscriberlist	Print a list of all active notification subscriptions
../querytree	Search device description for specific elements

Depending on the read and write access rights, the following services can be applied to elements of type data:

Service	Description
../getdata	Reading the value of the element
../setdata	Write the value of the element

Example: Reading properties of an element

59782

Task: Determine the data type and value range of the `accessrights` parameter.

Solution: Read the properties of the element `iotsetup/accessrights` of the `getelementinfo` service. The fields `type` (data type) and `valuation` (range of values) contain the required information.

- Request:

```
{
  "code":"request",
  "cid":4711,
  "adr":"getelementinfo",
  "data":{"adr":"iotsetup/accessrights"}
}
```

- Response:

```
{
  "cid":4711,
  "data":{
    "identifier":"accessrights",
```

```

"type":"data",
"uid":null,
"profiles":["parameter"],
"format":{"
"type":"enum",
"namespace":"json",
"encoding":"integer",
"valuation":{"
"valuelist":{"
"0":"Fieldbus + IoT",
"1":"Fieldbus + IoT (read-only)",
"3":"IoT only"}}}},
"code":200
}

```

The accessrights parameter has the data type ENUM with the valid values "Fieldbus + IoT", "Fieldbus + IoT (read only)" and "IoT only".

Example: output subtree

61149

Task: Output all direct sub-elements of the node firmware.

Solution: Use the service gettree to output the required subtree (root node: firmware, sub-levels to be shown: 1)

- Request:

```

{
"code":"request",
"cid":4711,
"adr":"gettree",
"data":{"
"adr":"firmware",
"level":1}
}

```

- Response:

```

{
"cid":4711,
"data":{"
"identifier":"firmware",
"type":"structure",
"profiles":["
software","software/uploadablesoftware"],
"subs":["
{
"identifier":"version","type":"data","profiles":["parameter"],
"format":{"type":"string","namespace":"json","encoding":"UTF-8"}},
{
"identifier":"type","type":"data",
"format":{"type":"string","namespace":"json","encoding":"UTF-8"}},
{
"identifier":"install","type":"service"},
{
"identifier":"factoryreset","type":"service"},
{
"identifier":"signal","type":"service"},
{
"identifier":"container","type":"data",
"format":{"type":"binary","namespace":"json","encoding":"base64"}},

```

```
{
"identifier":"reboot","type":"service"}]
},
"code":200
}
```

Example: Read several parameter values of the IO-Link master simultaneously

33840

Task: The following current values are to be read by the IO-Link master: temperature, serial number

Solution: Read the current parameter values using the `getdatamulti` service (data point temperature: `/processdatamaster/temperature`; data point serial number: `/deviceinfo/serialnumber`)

- Request:

```
{
"code":"request",
"cid":4711,
"adr":"/getdatamulti",
"data":{"datatosend":["/processdatamaster/temperature","/deviceinfo/serialnumber"]}
}
}
```

- Response:

```
{
"cid":4711,
"data":{"processdatamaster/temperature":{"code":200,"data":44},
"deviceinfo/serialnumber":{"code":200,"data":"000174210147"}},
"code":200
}
```

Example: Browsing device description

61150

Task: List all elements with the designation "status" and the profile "runcontrol".

Solution: Use the service `querytree` to browse the device description with the parameters "status" (name) and "runcontrol" (profile)

- Request:

```
{
"cid":4711,
"adr":"querytree",
"code":"request",
"data":{"
"profile":"runcontrol",
"name":"status"}
}
```

- Response:

```
{
"cid":4711,
"data":{"
"adrList":["
device/connections/mqttConnection/status",
device/connections/mqttConnection/mqttCmdChannel/status"]},
"code":200
}
```

DNS support

61151

The IoT Core supports the Domain Name System (DNS) service. Instead of the concrete IP address, the corresponding host name can be used in requests. DNS can be used both for addressing the IoT core and for addressing network participants.

Example: Using DNS support

61152

Example 1: gettree

Synonymous requests:

- `http://192.168.23.70:8080/gettree`
- `http://example.org:8080/gettree`

Example 2: subscribe

Synonymous requests:

- with IP address

```
{
  "cid": 11
  "code": 10,
  "adr." "setasync/datachanged/subscribe",
  "data":{
    "datatosend":["setasync"],
    "callback":"192.168.23.70:8080/dump"}
}
```

- with host name

```
{
  "cid": 11
  "code": 10,
  "adr": "setasync/datachanged/subscribe",
  "data":{
    "datatosend":["setasync"],
    "callback":"http://example.com:8080/dump"}
}
```

Setting the storage duration

61153

The IoT Core offers the possibility to set the storage duration of data and notifications. The Services **Service: setdata** (→ S. [130](#)) and **Service: subscribe** (→ S. [132](#)) therefore have the parameter "duration".

Example: Subscribing to notifications

61154

Task: The current values of the following parameters are to be sent regularly to a network server with IP address 192.168.0.4:

- Product name of the IO-Link Devices an IO-Link port X02
- Cyclic input data of the IO-Link Devices an IO-Link port X02
- Operating temperature of the IO-Link master.

The subscription is only to be active until the next restart of the IO-Link master.

Solution: Subscribe to the required data using the subscribe service.

- Request:

```
{
  "code": "request",
  "cid": 4711,
  "adr": "/timer[1]/counter/datachanged/subscribe",
  "data": {
    "callback": "http://192.168.0.4:80/temp",
    "datatosend": [
      "/iolinkmaster/port[2]/iolinkdevice/productname",
      "/iolinkmaster/port[2]/iolinkdevice/pdin",
      "/processdatamaster/temperature"],
    "duration": "uptime"
  }
}
```

- Response:

```
{
  "cid": 4711,
  "code": 200
}
```

9.2.4 IoT: Configuring access rights

59785

Substructure: `iotsetup`

Available data points:

Name	Description	Access
<code>../accessrights</code>	Access rights to the IO-Link master	rw

rw ... read and write



If in IoT and EtherCAT projection software the parameter [Access Rights] is = [EtherCAT + IoT], the parameter values set in the EtherCAT projection software will always apply.

If in IoT the parameter [Access Rights] is = [IoT only], set the parameter [Access Rights] = [Keep settings] in the EtherCAT projection software.

If in LR DEVICE the parameter [Access Rigts] is = [EtherCAT + IoT (read-only)], write access to the device configuration via LR DEVICE and IoT core services is blocked. To enable write access again, set the parameter to [EtherCAT + IoT] via fieldbus configuration software.

Changes of the parameter [Access Rights] will only be effective after restarting the IO-Link master (→ **Firmware: Reboot the device** (→ S. [33](#))).

9.2.5 IoT: Configuring IP settings

61155

Substructure: `iotsetup`

Available data points:

Name	Description	Access
<code>../network/dhcp</code>	Configuration of the IP settings of the IoT port	rw
<code>../network/ipaddress</code>	IP address of the IoT port	rw
<code>../network/subnetmask</code>	Subnet mask of the network segment	rw
<code>../network/ipdefaultgateway</code>	IP address of the network gateway	rw

rw ... read and write

Applicable services:

Name	Description
<code>../network/setblock</code>	Write all values of the substructure blockwise



Change the IP parameters in the substructure network only blockwise with the `setblock` service!

9.2.6 IoT: Configuring security mode

54683

The access to the IoT interface of the IO-Link master can be protected with a security mode:

Substructure: `iotsetup`

Available data points:

Name	Description	Access
<code>../security/securitymode</code>	active security mode	rw
<code>../security/password</code>	Password for authentication (Base64 coded)	w

rw ... read and write

w ... write only



Valid character set for the Base64 coding / decoding of the password: UTF-8

Online tool for coding / decoding: → www.base64encode.org

Note: Security mode

54684

The security mode enables restricting access to the IO-Link master and the connected IO-Link devices from the IT network. In the activated security mode, the following restrictions apply:

- Access only with authentication (password-protected user account)
- Access only via secure https connection (Transport Layer Security - TLS)



The security mode only protects the access to the device via the IoT interface.

The standard value for users is: administrator

The set password cannot be read with `getdata`.

The current status of the security function can be read with the `getidentity` service (→ **Service: `getidentity`** (→ S. [123](#))).

For the authentication, the user must additionally provide the POST requests with a valid user name and password in the field "auth". The user name and the password will be shown as Base64-coded character strings (→ **Example: Request with authentication** (→ S. [48](#))).

The following requests can be done if the security mode is enabled, also without authentication:

- `/getidentity`
- `/deviceinfo/vendor/getdata`
- `/deviceinfo/productcode/getdata`

Example: Activate security mode

54701

Task: Activate the security mode of the IO-Link interface of the IO-Link master. Set the password "password" (Base64 coded: cGFzc3dvcmQ=)

Solution: The activation consists of 2 steps:

1 Activate security mode

Use service setdata with datapoint `iotsetup/security/securitymode` to activate the security mode.

- Request:

```
{
  "code": "request",
  "cid": -1,
  "adr": "/iotsetup/security/securitymode/setdata",
  "data": {"newvalue": "1"}
}
```

- Response:

```
{
  "cid": -1,
  "code": 200
}
```

2 Set required password

Use service setdata with data point `iotsetup/security/password` to set the required password.

- Request:

```
{
  "code": "request",
  "cid": -1,
  "adr": "/iotsetup/security/password/setdata",
  "data": {"newvalue": "cGFzc3dvcmQ="}
}
```

- Response:

```
{
  "cid": -1,
  "code": 200
}
```

Example: Request with authentication

54685

Task: The temperature of the IO-Link master is to be read. The security function is enabled (current password: password).

Solution: Read the data point `processdatamaster/temperature` with the `getdata` service. The request must be sent using `https`. The user name and the password are transferred as a Base64-coded character string ("administrator" = "YWRtaW5pc3RyYXRvcg==", "password" = "cGFzc3dvcmQ=")

- Request:

```
{
  "code": "request",
  "cid": -1,
  "adr": "processdatamaster/temperature/getdata",
  "auth": {"user": "YWRtaW5pc3RyYXRvcg==", "passwd": "cGFzc3dvcmQ="}
}
```

- Response:

```
{
"cid":-1,
"data":{"value":37},
"code":200
}
```

Example: reset password

54686

Task: The existing password is to be reset.

Solution: To reset a password, disable the security mode. To disable it, enter the user name and the password (the fields "user" and "passwd").

- Request:

```
{
"code":"request",
"cid":-1,
"adr":"iotsetup/security/securitymode/setdata",
"data":{"newvalue":0},
"auth":{"user":"YWRtaW5pc3RyYXRvcg==","passwd":"SW9UNG1mbQ=="}
}
```

- Response:

```
{
"cid":-1,
"code":200
}
```

9.2.7 Fieldbus: Configuring the fieldbus interface

33892

The AL1332 in das EtherCATnetwork can be integrated via the field bus interface (ports X21 / X22).

Substructure: `fieldbussetup`

Available data points:

Name	Description	Access
<code>../hostname</code>	Name of the IO-Link master in the fieldbus project	rw
<code>../fieldbusfirmware</code>	Firmware version of the IO-Link master	r
<code>../connectionstatus</code>	Status of the connection to the EtherCAT network	r

r ... read only

rw ... read and write

9.2.8 IO-Link ports: Setting the operating mode of pin 4 (US)

59793

Substructure: `iolinkmaster/port[n]` (n = 1...8).

Available data points:

Name	Description	Access
<code>../mode</code>	Operating mode of the IO-Link port	rw*
<code>../mastercycletime_preset</code>	Cycle time of the data transfer at the IO-Link port (value in ms)	rw*
<code>../mastercycletime_actual</code>	Current cycle time of the data transfer at the IO-Link port (value in ms)	r
<code>../comspeed</code>	Data transfer rate of the IO-Link port	r

r ... read only

rw ... read and write

* ... only changeable, if the <Feldbus> plc is not in RUNNING state

9.2.9 IO-Link ports: Configuring device validation and data storage

59792

Substructure: `iolinkmaster/port[n]` (n = 1...8).

Available data points:

Name	Description	Access
<code>../validation_datastorage_mode</code>	Response of the IO-Link port when a new IO-Link device is connected	rw*
<code>../validation_vendorid</code>	IO-Link ID of the manufacturer that is to be validated	rw*
<code>../validation_deviceid</code>	IO-Link ID of the device that is to be validated	rw*
<code>../datastorage</code>	Structure for port data storage	rw
<code>../datastorage/maxsize</code>	Maximum size of the data storage content (in bytes)	r
<code>../datastorage/chunksize</code>	Size of a data segment (in bytes)	r
<code>../datastorage/size</code>	Size of the data storage content (in bytes)	r

r ... read only

rw ... read and write

* ... can only be changed if the EtherCAT PLC is not in RUNNING state

Applicable services:

Service	Description
<code>../validation_useconnecteddevice</code>	Validate the IO-Link device connected to the IO-Link port*
<code>../datastorage/getblobdata</code>	Reading the content of the data storage area
<code>../datastorage/stream_set</code>	Transfer an individual data segment*
<code>../datastorage/start_stream_set</code>	Start sequential transmission of several data segments*

* ... can only be changed if the EtherCAT PLC is not in the RUNNING state

Example: Clone the Data Storage of an IO-Link port

52344

Task: Save the Data Storage of IO-Link port X02 of IO-Link master 1 and restore the data at IO-Link master 2.

Solution: The cloning process consists of 2 steps. In the first step, the Data Storage of the IO-Link port of IO-Link master 1 is saved. In the second step, the saved data is restored at the Data Storage of port IO-Link port of IO-Link master 2.

Save Data Storage:

1 Preparations

- ▶ Read size of segments of Data Storage (h = number of bytes):
`{"code": "request", "cid": -1, "adr": "/iolinkmaster/port[2]/datastorage/chunksize/getdata"}`
 Example: h = 256
- ▶ Read total size of Data Storage area (g = number of bytes):
`{"code": "request", "cid": -1, "adr": "/iolinkmaster/port[2]/datastorage/size/getdata"}`
 Example: g = 550
- ▶ Calculate the number of reading steps n: n = first integer value to which the following applies: $g < n * h$
 Example: n = 3, because $550 < 3 * 256$

2 Read Data Storage of IO-Link port

- ▶ Read Data Storage segment by segment ("pos" is the byte offset, at which the reading process with length "length" starts).
`{"code": "request", "cid": -1, "adr": "/iolinkmaster/port[2]/datastorage/getblobdata", "data": {"pos": 0, "length": h}}`
`{"code": "request", "cid": -1, "adr": "/iolinkmaster/port[2]/datastorage/getblobdata", "data": {"pos": h, "length": h}}`
`{"code": "request", "cid": -1, "adr": "/iolinkmaster/port[2]/datastorage/getblobdata", "data": {"pos": 2*h, "length": h}}`

...

```
{"code": "request", "cid": -1, "adr": "/iolinkmaster/port[2]/datastorage/getblobdata", "data": {"pos": n*h, "length": h}}
```

Example:

1st read request: pos = 0, length = 256

2nd read request: pos = 256, length = 256

3rd read request: pos = 512, length = 256

- > Each segment value will be returned as BASE64 coded string.
- ▶ Join segments.

Restore Data Storage:

1 Preparations

- ▶ Determine the size of the saved Data Storage value (n = number of bytes).

Example: n = 550

- ▶ Read size of segments (s = number of bytes):

```
{"code": "request", "cid": -1, "adr": "/iolinkmaster/port[1]/datastorage/chunksize/getdata"}
```

Example: s = 256

2 Transfer Data Storage strings

- ▶ Start transfer of Data Storage string ("size" = size of Data Storage string):

```
{"code": "request", "cid": -1, "adr": "/iolinkmaster/port[1]/datastorage/start_stream_set", "data": {"size": n}}
```

Example: size = 550

- ▶ Transfer Data Storage string segment by segment ("value" = string value of length s):

```
{"code": "request", "cid": -1, "adr": "/iolinkmaster/port[1]/datastorage/stream_set", "data": {"value":  
"aWZtfglAAABBTDF4NXhfY25faXRfdDluMi43Nw..."}}
```

9.2.10 IO-Link ports: Configuring data transfer to LR AGENT or LR SMARTOBSERVER

59795

Substructure: iolinkmaster/port[n] (n = 1...8).

Available data points:

Name	Description	Access
../senddatatosmob	Process data to LR AGENT or LR SMARTOBSERVER	rw

rw ... read and write

9.2.11 IO-Link ports: Reading / writing process data

61156

Substructure: iolinkmaster/port[n] (n = 1...8)

Available data points:

Name	Description	Access
../pin2in	Value of the digital input on pin 2 of the IO-Link port	r
../iolinkdevice/pdin	Value of the IO-Link input on pin 4 of the IO-Link port	r
../iolinkdevice/pdout	Value of the IO-Link output on pin 4 of the IO-Link port	rw*

r ... read only

rw ... read and write

*... can only be changed if the fieldbus PLC is not in RUNNING state

Example: Read IO-Link process data (operating mode "IO-Link")

33842

Task: Read the current measured value of the ifm temperature sensor TN2531 at IO-Link port X02

Solution: Read the data point for the process input data with the getdata service.

- Request:

```
{
"code": "request",
"cid": 4711,
"adr": "/iolinkmaster/port[2]/iolinkdevice/pdin/getdata"
}
```

- Response:

```
{
"cid": 4711,
"data": {"value": "03C9"},
"code": 200
}
```

The return value is given in hexadecimal format. Besides the temperature value the return value comprises additional information (→ IO Device Description (IODD) of the sensor). The temperature value is shown in bits 2 to 15.

0x03C9 = 0b1111001001

Temperature value: 0b11110010 = 242

Therefore: The current temperature value is 24.2 °C.

Example: Writing IO-Link value (operating mode "IO-Link")

59804

Task: Switch on the buzzer of DV2500 at IO-Link Port X2. The DV2500 operates in On/Off mode.

Solution: The IODD of the DV2500 shows the structure of the IO-Link process value (→ e.g. LED activity). The buzzer will be switched using bit 40 of the process value (OFF = 0, ON = 1).

To switch the buzzer:

1. Read the current process value (→ **Example: Read IO-Link process data (operating mode "IO-Link")** (→ S. 53)).
2. Set bit 40 of the read value to 1.
3. Write the process value to the IO-Link device.

Example:

Read process value:

0x0000 0000 004D = 0b0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0100 1101

New process value:

0b0000 0001 0000 0000 0000 0000 0000 0000 0000 0000 0100 1101 = 0x0100 0000 004D

- Request:

```
{
"code": "request",
"cid": 10,
"adr": "iolinkmaster/port[2]/iolinkdevice/pdout/setdata",
"data": {"newvalue": "01000000004D"}
}
```

- Response:

```
{
"cid": 10,
"code": 200
}
```

Example: Writing digital output (operating mode "DO")

59803

Task: Set the output value of the IO-Link devices at IO-Link Port X1 to "ON". The operating mode of the IO-Link port is "Digital Output (DO)".

Solution: Write the value 1 to data point pdout. The value has to be written as hexadecimal value with a length of 1 byte (OFF = "00", ON = "01").

- Request:

```
{
"code": "request",
"cid": 10,
"adr": "iolinkmaster/port[1]/iolinkdevice/pdout/setdata",
"data": {"newvalue": "01"}
}
```

- Response:

```
{
"cid": 10,
"code": 200
}
```

Example: Reading digital input (operating mode "DI")

59802

Task: Read the current input value of the IO-Link device at IO-Link port X5. The operating mode of the IO-Link port is "Digital Input (DI)".

Solution: Read the value of data point pdin. The value will be returned as hexadecimal value with a length of 1 byte (OFF = "00", ON = "01").

- Request:

```
{
"code":"request",
"cid":10,
"adr":"iolinkmaster/port[5]/iolinkdevice/pdin/getdata"
}
```

- Response:

```
{
"cid":10,
"data":{"value":"00"},
"code":200
}
```

9.2.12 IO-Link ports: Indicating port events

59796

Substructure: iolinkmaster/port[n] (n = 1...8).

Available data points:

Name	Description	Access
../portevent	Indication of the following events at IO-Link port n: <ul style="list-style-type: none"> plugging IO-Link device pulling IO-Link device changing operating mode of IO-Link port 	r

r ... read only



Subscribing events: → **Subscribing to notifications** (→ S. [62](#))

9.2.13 IO-Link devices: Accessing parameters

59800

The ifm IoT Core supports the configuration of the connected IO-Link devices. A parameter is accessed via IO-Link index and subindex (→ IO Device Description (IODD) of the device).

Substructure: iolinkmaster/port[n]/iolinkdevice (n = 1...8)

Applicable services:

Service	Description
../iolreadacyclic	Read a parameter of an IO-Link device (acyclic)
../iolwriteacyclic	Write a parameter of an IO-Link device (acyclic)

Example: Read the parameter value of an IO-Link device

33847

Task: Read the serial number of the ifm temperature sensor TN2531 at IO-Link port X02

Solution: Read the serial number with the `iolreadacyclic` service from the IO-Link device (index: 21, subindex: 0)

- **Request:**

```
{
  "code": "request",
  "cid": 4711,
  "adr": "/iolinkmaster/port[2]/iolinkdevice/iolreadacyclic",
  "data": {"index": 21, "subindex": 0}
}
```

- **Return:**

```
{
  "cid": 4711,
  "data": {"value": "4730323134323830373130"},
  "code": 200
}
```

The returned value is given in hexadecimal format. The conversion of the HEX value in a STRING value is: G0214280710

Example: Change the parameter value of an IO-Link device

33844

Task: Set the output configuration OUT1 of the ifm temperature sensor TN2531 at IO-Link port X02 to the value "Hnc / hysteresis function, normally closed".

Solution: Change the parameter [ou1] of the sensor to the value 4 using the `iolwritecyclicdata` service. The parameter can be accessed via IO-Link index 580, subindex 0 (→ IO-Link description of the sensor).

- Request:

```
{
"code": "request",
"cid": 4711,
"adr": "/iolinkmaster/port[2]/iolinkdevice/iolwritecyclic",
"data": {"index": 580, "subindex": 0, "value": "34"}
}
```

The value has to be given in hexadecimal format. The conversion of the STRING value in a HEX value is: 34.

- Response:

```
{
"cid": 4711,
"code": 200
}
```

9.2.14 IO-Link devices: Reading an writing device information

59797

Substructure: iolinkmaster/port[n]/iolinkdevice (n = 1...8)

Available data points:

Name	Description	Access
../status	Status of the connected IO-Link device	r
../vendorid	IO-Link ID of the vendor	r
../deviceid	IO-Link ID of the IO-Link device	r
../productname	Product name of the IO-Link device	r
../serial	Serial number of the IO-Link device	r
../applicationspecifictag	Device-specific identification (application tag)	rw

r ... read only
 rw ... read and write

9.2.15 IO-Link devices: Indicating IO-Link events

59798

Substructure: iolinkmaster/port[n]/iolinkdevice (n = 1...8).

Available data points:

Name	Description	Access
../iolinkevent	Indication of IO-Link events	r

r ... read only



Subscribing events: → **Subscribing to notifications** (→ S. [62](#))

9.2.16 Gateway: Resetting, rebooting and localising the device

59790

Substructure: firmware

Applicable services:

Name	Description
../factoryreset	Reset IO-Link master to factory settings
../reboot	Reboot IO-Link master
../signal	Trigger the flashing of the status LED

9.2.17 Gateway: Reading device information

52254

Substructure: deviceinfo

Available data points:

Name	Description	Access
../productcode	Article number	r
../vendor	Manufacturer	r
../devicefamily	Device family	r
../hwrevision	Hardware revision	r
../serialnumber	Serial number	r
../revision	Firmware version	r
../bootloaderrevision	Bootloader version	r
../extensionrevisions	Firmware and bootloader version	r
../fieldbustype	Fieldbus	r

r ... read only

Additional information about the AL1332 can be read with the service `getidentity` (→ **Service: `getidentity`** (→ S. [123](#))).

9.2.18 Gateway: Reading status and diagnostic information

61157

Substructure: processdatamaster

Available data points:

Name	Description	Access
../temperature	Temperature of the IO-Link master (value in °C)	r
../voltage	Present voltage value of the supply voltage US (value in mV)	r
../current	Present current value of the sensor supply US (value in mA)	r
../supervisionstatus	Status of the device supply US	r

r ... read only

9.2.19 Gateway: Updating the firmware

59789

Substructure: firmware

Available data points:

Name	Description	Access
../version	Software version	r
../type	Software type	r
../container	Structure for updating the firmware	w
../container/maxsize	Maximum size of the container structure (in bytes)	r
../container/chunksize	Size of a data segment (in bytes)	r
../container/size	Size of the container content (in bytes)	r

r = only read

w = write only

Applicable services:

Name	Description
../install	Install firmware transferred to the IO-Link master
../container/stream_set	Transfer an individual data segment
../container/start_stream_set	Start sequential transmission of several data segments

Example: Update firmware

52252

Task:

Update the firmware of the device; size of the firmware file: 356676 bytes

Solution:

The firmware is transferred to the device in fragments (chunks). The size of the fragments depends on the size of the flash memory of the IO-Link master. To transfer the firmware, the firmware file must be converted into a character string using BASE64.

1 Preparations

- ▶ Determine the size of the fragments (g = number of bytes):
{"code": "request", "cid": -1, "adr": "/firmware/container/chunksize/getdata"}
- ▶ Convert the firmware file into a BASE64 string.

2 Start the transfer of the firmware

- ▶ Start the transfer of the firmware via the service start_stream_set (parameter "size": size of the firmware file):
{"code": "request", "cid": -1, "adr": "/firmware/container/start_stream_set", "data": {"size": 356676}}

3 Load the firmware into the flash memory of the IO-Link master

- ▶ Send the BASE64 string of the firmware file to the IO-Link master fragment by fragment (value = string value with length g).
{"code": "request", "cid": -1, "adr": "/firmware/container/stream_set", "cid": -1, "data": {"value": "aWZtfgIAAABBTFDF4NXhfY25faXRfdDluMi43Nw..."}}
- ▶ Repeat step 3 until all fragments of the firmware file have been sent to the IO-Link master.
- > IO-Link master stores the segments received in the container area.

4 Install firmware

- ▶ Start the installation of the transmitted firmware.
{"code": "request", "cid": -1, "adr": "/firmware/install", "data": {}}

9.2.20 Gateway: Setting the application tag

59791

Substructure: devicetag

Available data points:

Name	Description	Access
../applicationtag	Name of the IO-Link master (application tag)	rw

rw ... read and write



For the storage of the applicationtag 32 bytes are available on the IO-Link master. If the memory area is exceeded during writing with setdata, the IoT core aborts the write process and returns the diagnostics code 400.

When writing the application tag, note the different memory requirements of the individual UTF-8 characters:

- characters 0-127: 1 byte per character
- characters >127: more than 1 byte per character

Example: Change name of the IO-Link master

a33823

Task: Set the name of the IO-Link master to AL1332 for the representation in the LR SMARTOBSERVER.

Solution: Change the parameter [Application Tag] with the setdata service to the value [AL1332].

The data point of the parameter [Application Tag] in the device description object is /devicetag/applicationtag.

- Request:

```
{
"code": "request",
"cid": 4711,
"adr": "/devicetag/applicationtag/setdata",
"data": {"newvalue": "AL1332"}
}
```

- Response:

```
{"cid": 4711, "code": 200}
```

9.2.21 Subscribing to notifications

61159

If a data point has the sub-element `datachanged`, the user can subscribe to notifications on value and condition changes. Notifications can be triggered by the expiration of a timer or an event. The IoT Core supports the output of notifications in CSV or JSON format.

Available data points:

Name	Description	Access
<code>timer[x]/counter</code>	Timer for triggering a notification	rw
<code>timer[x]/interval</code>	Cycle time of the update of the subscribed values	rw
<code>iolinkmaster/port[n]/portevent</code>	Display of the following events on IO-Link port n: <ul style="list-style-type: none"> ▪ IO-Link device connected ▪ IO-Link device disconnected ▪ Operating mode of the IO-Link port changed 	rw
<code>iolinkmaster/port[n]/iolinkdevice/iolinkevent</code>	Display of IO-Link events	rw

r ... read only
rw ... read and write
x = [1,2]
n = 1...8

Applicable services:

Name	Description
<code>../datachanged/subscribe</code>	Subscribe to notification
<code>../datachanged/unsubscribe</code>	Unsubscribe notification
<code>../datachanged/getsubscriptioninfo</code>	Show information about notifications

Additionally, the user can use **Service: `getsubscriberlist`** (→ S. [124](#)) show all active subscriptions.

Example: Subscribing to notifications

61160

Task: The current values of the following parameters are to be sent regularly to a network server with IP address 192.168.0.4:

- cyclic input data of the IO-Link Devices an IO-Link port X02
- Operating temperature of the IO-Link master.

Solution: Subscribe to the required data using the subscribe service.



The following options are additionally available:

- via WebSockets (`ws://`): **Example: Subscribing notifications via WebSocket** (→ S. [66](#))
- via MQTT (`mqtt://`): **Example: Configuring the MQTT command channel** (→ S. [70](#))

- Request:

```
{
"code": "request",
"cid": 4711,
"adr": "/timer[1]/counter/datachanged/subscribe",
"data":
{
"callback": "http://192.168.0.4:80/temp",
```

```
"datatosend":[
"/iolinkmaster/port[2]/iolinkdevice/pdin",
"/processdatamaster/temperature"]
}
}
```

In addition, the time interval of the timer[1] must be set to a value between 500 ms and 2147483647 ms.

- Request:

```
{
"code":"request",
"cid":4712,
"adr":"/timer[1]/interval/setdata",
"data":{"newvalue":500}
}
```

- Response:

```
{
"cid":4712,
"code":200
}
```

- Notification (JSON)

```
{
"code":"event",
"cid":4711,
"adr":"","
"data":{"
"eventno":"6317",
"srcurl":"/timer[1]/counter/datachanged",
"payload":{"
"/timer[1]/counter":{"code":200,"data":1},
"/processdatamaster/temperature":{"code":200,"data":39},
"/iolinkmaster/port[2]/iolinkdevice/pdin":{"code":200,"data":"03B0"}}}}
}
```

Example: Changing a subscription

61161

Task: The existing subscription (**Example: Subscribing to notifications** (→ S. 62)) is to be changed. Instead of the temperature of the IO-Link master, the operating voltage applied is to be transmitted.

Solution: Overwrite the existing subscription. For this purpose, the parameter values for "cid" and "callback" in the request must be the same as those of the existing subscription.

- Request:

```
{
"code":"request",
"cid":4711,
"adr":"/timer[1]/counter/datachanged/subscribe",
"data":{"
"callback":"http://192.168.0.4:80/temp",
"datatosend":[
"/iolinkmaster/port[2]/iolinkdevice/pdin",
"/processdatamaster/voltage"]}}
}
```

Example: Subscribing to notifications in CSV format

61162

Task: Every 2 seconds, the current values of the following parameters are to be sent to a network server with the IP address 192.168.0.4

- cyclic IO-Link input data of the IO-Link device at port X02
- Operating temperature of the IO-Link master.

The data should be transmitted in CSV format (comma separator).

Solution:

- ▶ Use the subscribe service to subscribe to the required data and set the output format to "csv0".



Data in CSV format can only be sent via TCP protocol.

- Request:

```
{
"cid": 1,
"adr": "/timer[1]/counter/datachanged/subscribe",
"code": "request",
"callback": "tcp://192.168.50.59:1883/topic",
"codec": "csv0",
"data": {
"datatosend": [
"/iolinkmaster/port[2]/iolinkdevice/pdin",
"/processdatamaster/temperature"]
}
```

- ▶ Set the interval of the timer to 2 seconds:

- Request:

```
{
"code": "request",
"cid": 4712,
"adr": "/timer[1]/interval/setdata",
"data": {"newvalue": 2000}
}
```

The cyclically sent notification has the following structure:

```
/timer[1]/counter/datachanged,6317,200,1,200,39,200,03B0
```

Example: Unsubscribing from notifications

61163

Task: The existing subscription (**Example: Subscribing to notifications** (→ S. 62)) is to be deleted.

Solution: Use the unsubscribe service to delete the subscription. For this purpose, the value of the parameter "callback" in the request must be equal to the value of the existing subscription.

```
{
"code": "request",
"cid": 4711,
"adr": "/timer[1]/counter/datachanged/unsubscribe",
"data": {
"callback": "http://192.168.0.4:80/temp"
}
```

Example: Checking subscriptions

61164

Task: Information about the existing subscription (**Example: Subscribing to notifications** (→ S. [62](#)) Show **Example: Subscribing to notifications** (→ S. [62](#))).

Solution: Use the service getsubscriptioninfo and the parameter values cid, "adr" and "callback" of the existing subscription to retrieve the information.

- Request:

```
{
"code": "request",
"cid": 4711,
"adr": "/timer[1]/counter/datachanged/getsubscriptioninfo",
"data": {
"callback": "http://192.168.0.4:80/temp"}
}
```

- Response:

```
{
"cid." 4711,
"data": {
"callback": "http://192.168.0.4:80/temp",
"datatosend": [
"/iolinkmaster/port[2]/iolinkdevice/productname",
"/iolinkmaster/port[2]/iolinkdevice/pdin",
"/processdatamaster/temperature"]},
"code": 200
}
```

9.2.22 Using Web Socket

61165

The IoT Core supports communication via WebSocket protocol. With Web Sockets, the user can establish a full-duplex communication channel via a TCP connection.

WebSockets can be used for the following services:

- subscribe / unsubscribe



Maximum number of WebSocket connections: 8
Fail-safe WebSocket connections (wss://) are not supported.

To transmit notifications via a WebSockets connection:

- ▶ Establish the WebSocket connection (e.g. "ws://192.168.0.55:80/websocket")
 - Option 1: without parameter "callback"
- ▶ make subscribe/unsubscribe request without parameter "callback".
- > IoT-Core sends notifications about existing WebSocket connections.
 - Option 2. with parameter "callback"
- ▶ make subscribe/unsubscribe requests with parameter "callback" ("ws:///myTopic").
- > IoT-Core sends notifications about existing WebSocket connections to the topic myTopic.

Example: Subscribing notifications via WebSocket

61166

Task: The current values of the following parameters are to be sent regularly to the data sink myTopic via an existing WebSocket connection:

- Product name of the IO-Link Devices an IO-Link port X02
- cyclic input data of the IO-Link Devices an IO-Link port X02
- Operating temperature of the IO-Link master.

Solution: Subscribe to the required data using the subscribe service.

- Request:

```
{
"code": "request",
"cid": 4711,
"adr": "/timer[1]/counter/datachanged/subscribe",
"data": {
"callback": "ws:///myTopic",
"datatosend": [
"/iolinkmaster/port[2]/iolinkdevice/productname",
"/iolinkmaster/port[2]/iolinkdevice/pdin",
"/processdatamaster/temperature" ]}
}
```

If the notifications are to be transmitted via the existing WebSocket connection, but without a special data sink, the callback parameter is not required.

- Request:

```
{
"code": "request",
"cid": 4711,
"adr": "/timer[1]/counter/datachanged/subscribe",
"data": {
"datatosend": [
```

```
"/iolinkmaster/port[2]/iolinkdevice/productname",  
"/iolinkmaster/port[2]/iolinkdevice/pdin",  
"/processdatamaster/temperature"]}  
}
```

9.2.23 MQTT support

61168

The IoT Core supports the MQTT protocol. The protocol allows an MQTT client to communicate with the IoT Core via an MQTT broker to request and receive data. The IoT Core can publish data via the MQTT connection.

Configuring the MQTT command channel

61169

To enable MQTT communication, the user needs to activate and configure an MQTT command channel.

Substructure: `connections/mqttConnection`

Name	Description	Access
<code>../type</code>	Type of the connection (MQTT)	r
<code>../status</code>	Global MQTT status	r
<code>../status/preset</code>	Presetting of the MQTT status; Basic settings: running	r
<code>../MQTTSetup</code>	Substructure for general MQTT settings	w
<code>../MQTTSetup/QoS</code>	Quality of Service of the MQTT communication <ul style="list-style-type: none"> ▪ 0: QoS Level 0 - PUBLISH (without confirmation) ▪ 1: QoS Level 1 - PUBLISH > PUBREC (one-time confirmation) ▪ 2: QoS Level 2 - PUBLISH > PUBREC > PUBREL > PUBCOMP (double confirmation) 	rw
<code>../MQTTSetup/version</code>	MQTT version	r
<code>../mqttCmdChannel</code>	Substructure of the MQTT command channel	w
<code>../mqttCmdChannel/type</code>	Type of the MQTT command channel	r
<code>../mqttCmdChannel/status</code>	Status of the MQTT command channel	r
<code>../mqttCmdChannel/status/preset</code>	Presetting of the MQTT status; Basic setting: stopped	r
<code>../mqttCmdChannel/mqttCmdChannelSetup</code>	Structure for settings of the command channel	w
<code>../mqttCmdChannel/mqttCmdChannelSetup/brokerIP</code>	IP address of the MQTT broker	rw
<code>../mqttCmdChannel/mqttCmdChannelSetup/brokerPort</code>	Port number of the MQTT broker	rw
<code>../mqttCmdChannel/mqttCmdChannelSetup/cmdTopic</code>	Designation of the MQTT topic	rw
<code>../mqttCmdChannel/mqttCmdChannelSetup/defaultReplyTopic</code>	Standard response topic	rw

Applicable services:

Name	Description
<code>../status/start</code>	Enable MQTT
<code>../status/stop</code>	Deactivate MQTT
<code>../status/reset</code>	Reset MQTT
<code>../mqttCmdChannel/status/start</code>	Activate MQTT command channel
<code>../mqttCmdChannel/status/stop</code>	Deactivate MQTT command channel
<code>../mqttCmdChannel/status/reset</code>	Reset MQTT command channel



Notes on the states of an MQTT connection: **Note: Connection states** (→ S. [69](#))

To create an MQTT connection, perform the following steps in sequence:



Ensure that the MQTT broker can be reached and that the selected port of the MQTT broker is enabled for data transmission.

Max. number of simultaneous MQTT connections: 10


Wildcards "+" and "#" in topics are not supported.

- ▶ Activate MQTT command channel.
- ▶ Set the IP address of the MQTT.
- ▶ Set the port number of the MQTT broker.
- ▶ Set topic.
- ▶ Set standard response topic.
- > The command channel is created with the selected properties.
- > The user can publish on the topic with the IoT Core.
- > MQTT clients can subscribe to the topic.

Note: Connection states

61170

The following status diagram shows the influence of the services "start", "stop" and "reset" on the status of an MQTT connection:



After the initialisation in the "init" state has been completed, the connection automatically changes to the "running" state.

The connection automatically switches to the "error" state if at least one of the following events occurs:

- no MQTT broker available

Example: Configuring the MQTT command channel

61171

Task: Configuring and activating the MQTT command channel (IP address MQTT broker: 192.168.82.100, port: 1883, topic: abc).

Solution:

► Check whether MQTT broker can be reached and the port has been released.

► Activate command channel

• Request:

```
{
"code": "request",
"cid": 4711,
"adr": "/connections/mqttConnection/MQTTSetup/mqttCmdChannel/status/start"
}
```

► Set the IP address of the MQTT broker/server.

• Request:

```
{
"code": "request",
"cid": 4712,
"adr": "/connections/mqttConnection/mqttCmdChannel/mqttCmdChannelSetup/brokerIP/set
data"
"data": {"192.168.82.100"}
}
```

► Set the port number of the MQTT broker/server.

• Request:

```
{
"code": "request",
"cid": 4713,
"adr": "/connections/mqttConnection/mqttCmdChannel/mqttCmdChannelSetup/brokerPort/s
etdata"
"data": {"1883"}
}
```

► Set topic.

• Request:

```
{
"code": "request",
"cid": 4714,
"adr": "/connections/mqttConnection/mqttCmdChannel/mqttCmdChannelSetup/cmdTopic/set
data"
"data": {"abc"}
}
```

► Set standard response topic.

• Request:

```
{
"code": "request",
"cid": 4715,
"adr": "/connections/mqttConnection/mqttCmdChannel/mqttCmdChannelSetup/defaultReply
Topic/setdata"
"data": {"xyz"}
}
```

► Set the QoS.

• Request:

```
{
"code":"request",
"cid":4716,
"adr":"/connections/mqttConnection/MQTTSetup/QoS/setdata",
"data":{"QoS2"}
}
```

Example: Publish the temperature to an MQTT broker

54687

Task: Publish the temperature of the IO-Link master to an MQTT broker (IP address MQTT broker: 192.168.82.100, port: 1883, topic: abc)

Solution:

- Request:

```
{
"code":"request",
"cid":-1,
"adr":"/timer[1]/counter/datachanged/subscribe",
"data":{"
"callback":"mqtt://192.168.82.100:1883/abc",
"datatosend":["processdatamaster/temperature"]
}
```

- Response:

```
{
"cid":-1,
"code":200
}
```

9.2.24 Using the IoT-Core Visualizer

Content


Managing notifications.....	73
Searching for elements in the device tree.....	75
Configuring IO-Link the master.....	76
Reading and writing process data.....	77
Updating the firmware.....	78

61173

The ifm-IoT Core Visualizer of the IO-Link master provides a graphical user interface for accessing functions of the ifm-IoT Core.

To start the IoT Core Visualizer:

- ▶ Start web browser.
- ▶ Call the following address: `http://ipaddress/web/subscribe`
- > Browser shows IoT Core Visualizer:



The navigation menu gives the user access to the following functions:

- [Notification]: Creating and managing notifications (subscribe / unsubscribe)
- [Elements]: Searching for elements in device description
- [Parameter]: Configuring IO-Link master
- [Processdata]: Reading and writing process data
- [Update]: Updating the firmware of the IO-Link master

Managing notifications

61174

The menu page allows you to perform the following functions

- Creating notifications
- Showing active notifications
- Deleting notifications (single, all)

Requirements:

- lot-Core Visualizer has been started.
- ▶ Click on [Notification].
- > The menu page for managing notifications appears.
- > The menu page shows all registered notifications in a table

Creating a new notification

61175

A wizard is used to register new notifications.

Requirements:

- The [Notification] menu page is open.
- ▶ Click on [+] on the right side of the table.
- > The wizard for the creation of notifications appears.

00-02-01-05-50-8b - online

Notification | Elements | Parameter | Processdata | Update

Add Subscription

1 Events — 2 Data — 3 Transfer Info

Event

Please choose one event, you want to subscribe to.

Search for ...

- counter
00-02-01-05-50-8b/timer[1]/counter/datachanged
- counter
00-02-01-05-50-8b/timer[2]/counter/datachanged
- preset
00-02-01-05-50-8b/connections/mqttconnection/status/preset/datachanged
- status
00-02-01-05-50-8b/connections/mqttconnection/status/datachanged
- qos
00-02-01-05-50-8b/connections/mqttconnection/mqttsetup/qos/datachanged
- preset
00-02-01-05-50-8b/connections/mqttconnection/mqtcmdchannel/status/preset/datachanged

CANCEL NEXT >

- ▶ Use the wizard to enter the required notification parameters step by step.
- > Created notification subscription is displayed in the table.



For cyclical notifications via timer[1] or timer[2], the user also needs to set the interval time of the timer in question.

Deleting a notification

61176

Requirements:

- The [Notification] menu page is open.
- At least one notification is active.
- ▶ Click on [x] in the column [Unsubscribe].
- > The selected notification will be deleted (unsubscribe).

Searching for elements in the device tree

61177

The [Elements] menu page allows you to search the device description for elements with specific properties (status, profile, name) and to output the results.

Requirements:

- IoT-Core Visualizer has been started.
- ▶ Click on [Elements].
- > The input mask appears.

00-02-01-05-50-8b - online

Notification | **Elements** | Parameter | Processdata | Update

Search for ...

identifier

profile

type

Processdatamaster Deviceinfo Timer[1] Timer[2] lotsetup Fieldbussetup Connections Iolinkmaster
Firmware Devicetag

^ 00-02-01-05-50-8b

getidentity	00-02-01-05-50-8b/getidentity	type: service profiles: undefined	Copy URL
gettree	00-02-01-05-50-8b/gettree	type: service profiles: undefined	Copy URL
querytree	00-02-01-05-50-8b/querytree	type: service profiles: undefined	Copy URL

- ▶ Enter the search criteria of the required item in the [identifier], [profile] and [type] boxes.
- ▶ Click on [Search for ...].
- > IoT-Core Visualizer searches device description for elements with selected search criteria.
- > The result list shows all elements found.

Configuring IO-Link the master

61178

The [Parameter] menu page allows you to configure the IO-Link master.

Available options:

- Reading and writing individual parameters
- Backup and restore the current configuration of the machine.

Requirements:

- Iot-Core Visualizer has been started.
- ▶ Click on [Parameter].
- > The menu page shows the available parameters of the IO-Link master.
- > Current parameter values are displayed.
- > Editable parameters can be changed.

00-02-01-05-50-8b - online

Notification	Elements	Parameter	Processdata	Update				
Deviceinfo	Timer[1]	Timer[2]	iotsetup Network k	Fieldbussetup	Connections	iolinkmaster	Firmware	Devicetag
^ iotsetup								
accessrights			iot only		Type:	enum		
					Namespace:	json		
					Encoding:	integer		
					Valuation:	valuelist:		
						0:		
						1:		
						3:		
v network								
smobip			192.168.82.2		Type:	string		
					Namespace:	json		
					Encoding:	utf-8		
					Valuation:	minlength:		

To change a parameter:

- ▶ Navigate to the desired parameter in the device description.
- ▶ Changing the parameter value
- ▶ Click on the pencil icon to save the change on the IO-Link master.
- > The changed parameter value is active.
- ▶ Optional: Repeat the procedure to change further parameter values.

Reading and writing process data

61179

The menu page allows the process data of the IO-Link master and the connected IO-Link devices to be read and written.

Requirements:

- lot-Core Visualizer has been started.
- ▶ Click on [Processdata].
- > Menu page shows the substructures of the device description that contain process data and events.
- > The current process values are displayed.
- > Editable process data can be changed.

00-02-01-05-50-8b - online

Notification | Elements | Parameter | **Processdata** | Update

Processdatamaster | Timer[1] | Timer[2] | Fieldbussetup | **iolinkmaster**
 Port[1] Port[2] Port[3]
 Port[4]

^ iolinkmaster

^ port[1]

portevent	FF0200	Type:	string
		Namespace:	json
		Encoding:	hexstring

^ iolinkdevice

vendorid	310	Type:	number
		Namespace:	json
		Encoding:	integer
		Valuation:	min: 0
			max: 65535

To change the value of a process date:

- ▶ Navigate to the required process date in the device description.
- ▶ Change the process value.
- ▶ Click on the pencil icon to save the change on the IO-Link master.
- > The changed process value is active.
- ▶ Optional: Repeat the procedure to change further process values.

Updating the firmware

61180

The [Update] menu page allows you to update the firmware of the IO-Link master:

Requirements:

- lot-Core Visualizer has been started.
- ▶ Click on [Update].
- > Menu page displays information about the current firmware version.

The screenshot shows the web interface for updating the firmware. At the top, there is a navigation bar with tabs: Notification, Elements, Parameter, Processdata, and Update (which is highlighted). Below the navigation bar, the page title is "Firmware" and the URL is "00-02-01-05-50-8b/firmware". The page is divided into two main sections: "Firmware" and "Container".

Firmware		Container	
Version:	AL1x2x_cn_ei_v3.1.44	Max size:	4194304
Type:	firmware	Chunk size:	4096
<input type="button" value="Load software file"/> choose software package		Size:	0
<input type="button" value="Update"/>			

- ▶ Click on [Load software file] and select a new firmware file (*.bin).
- ▶ Click on [Update] to start the update process.
- > The firmware of the IO-Link master will be updated.
- > The area shows the progress bar.
- > If the update process has been successful, the IO-Link master will restart automatically.

9.3 EtherCAT

Content

Install ESI file	79
Integrate the IO-Link master into the TwinCAT project	79
Configure IO-Link master	80
Configure IO-Link ports	80
Configure cyclic process data	80
Read and write cyclic process data	81
Read diagnostic and status information	82
Read IO-Link events	82
Configure IO-Link devices	83
EtherCAT: Programmers' notes	84

33673

On the field bus side, the device can be configured with any EtherCAT compatible projection software. The information in the following sections refers to the EtherCAT projection software TwinCAT 3.1.

9.3.1 Install ESI file

34067

To represent the AL1332 in a field bus projection software ifm electronic provides an ESI file (→ www.ifm.com). In the ESI file, all parameters, process data and their valid value ranges are defined.

To integrate the ESI file into EtherCAT projection software TwinCAT 3.1:

- ▶ Download ESI file of the device.
- ▶ Copy downloaded file to the following subdirectory of the TwinCAT installation directory:
`..\3.1\Config\Io\EtherCAT`
- ▶ Start TwinCAT.
- > TwinCAT loads the device description to the device catalogue.

9.3.2 Integrate the IO-Link master into the TwinCAT project

34080

The device is integrated into the project as EtherCAT slave.

Requirements

- > The ESI file of the IO-Link master is installed (→ **Install ESI file** (→ S. [79](#))).

1 Create/open EtherCAT project

- ▶ Launch EtherCAT projection software.
- ▶ Create a new project.
OR
Open an existing project.

2 Configure EtherCAT PLC and IO periphery

- ▶ Select and configure EtherCAT PLC and requested I/O periphery.
- > Project contains EtherCAT PLC and I/O periphery.

3 Insert the IO-Link master into the project

- ▶ In the Solution Explorer: Right-click on device to which the IO-Link master is connected.
- > Context menu appears.
- ▶ In the context menu: Select [Add new item...].
- > Window [Insert EtherCAT Device] appears.
- ▶ Select the IO-Link master in the device tree under [ifm electronic] > [ifm IO-Link master].
- ▶ Click on [OK] to add the selected device to the project.

- > TwinCAT adds IO-Link master to the project.

4 Save the project

- ▶ Save the project.

9.3.3 Configure IO-Link master

33867

The IO-Link master is configured via the CoE interface (→ TwinCAT-online help). The configuration is made via the following parameters:

Name	Description	Reference
Current Use Case	Access rights to the IO-Link master	→ Manufacturer Specific Index (0x2000) (→ S. 99)
Reset To Factory	Reset IO-Link master to factory settings	→ Manufacturer Specific Index (0x2000) (→ S. 99)

9.3.4 Configure IO-Link ports

33886

The IO-Link ports are configured via the CoE interface (→ TwinCAT-online help). The user can configure each IO-Link port separately. The configuration is made via the following parameters:

Name	Description	Reference
IO Settings	Configuration of the IO-Link ports X01...X08	→ Port Configuration (0x8000) (→ S. 102)
Vendor Specific IO Settings	Manufacturer-specific settings of the IO-Link ports X01...X08	→ Port Configuration (0x8000) (→ S. 102)



The AL1332 has no failsafe function for the outputs of the IO-Link ports. If the fieldbus connection is interrupted, the last used output values are written and marked as invalid.

9.3.5 Configure cyclic process data

33884

Type and number of cyclic input and output data on the IO-Link ports are defined via the fieldbus modules (→ **EtherCAT modules** (→ S. [96](#))). In the factory settings, all slots are configured with the module "IOL_4/4_I/O".

To configure the cyclic process data:

Requirements

- > AL1332 is integrated (→ **Integrate the IO-Link master into the TwinCAT project** (→ S. [79](#), **"Example: Reading properties of an element"** → S. [41](#))).

1 Open the device editor

- ▶ In the Solution Explorer: Double-click on the node of the AL1332.
- > The window shows the available configuration options.
- ▶ Select the tab [Slots].
- > The window shows the current configuration of the cyclic data.

2 Assign fieldbus modules

- ▶ In the left half of the table: Select click on slot of the requested IO-Link port.
- ▶ In the right half of the table: Click on the requested fieldbus module.
- ▶ Click on [<] to assign the requested fieldbus module to the slot.

3 Configure more IO-Link ports

- ▶ optional: repeat step 1 for further IO-Link ports.

- > Cyclic data is assigned to the fieldbus slots.
- > The Solution Explorer shows the configured modules as subelements of the device node.

4 Save the project

- ▶ Save the project.

9.3.6 Read and write cyclic process data

34217



- ▶ To check the validity of the cyclic process data, evaluate the PQI byte (→ **Mapping: Port Qualifier (0xF101)** (→ S. [106](#))).

Even with an interruption of the fieldbus connection the PQI byte indicates that the process data is valid. This can have unintended impact on the control process.

- ▶ Take suitable measures to detect an interruption of the fieldbus connection.

They cyclic process data of the IO-Link-Ports X01...X08 is accessible via the following index groups:

Name (Index)	Description	Reference
IO-Link inputs (0x6000)	Cyclic input data at the IO-Link ports X01...X08	→ IO-Link Inputs (0x6000) (→ S. 101)
IO-Link outputs (0x7000)	Cyclic output data at the IO-Link ports X01...X08	→ IO-Link Outputs (0x7000) (→ S. 101)



In operating mode "Digital Input (DI)" the digital process value of the IO-Link port will be mapped to the first byte of the input data (sub-index 0x01).

In operating mode "Digital Output (DO)" the digital process value of the IO-Link port will be mapped to the first byte of the output data (sub-index 0x01).

Valid values:

- 0x000 = OFF
- 0x001 = ON

During the configuration of the fieldbus slots TwinCAT automatically creates variables for the cyclic input and output data. They are found in groups in the folders under the respective fieldbus modules. The user can link the variables directly with the elements of a global variable list (GVL).

The following variables are created:

Group > Variable	Variable	Description
[TxPDO]	[input byte n]	Byte n of the cyclic input data of the fieldbus module
[RxPDO]	[output byte m]	Byte m of the cyclic output data of the fieldbus module

n = 0...(max. number of bytes on configured input data)-1

m = 0...(max. number of bytes on configured output data)-1

9.3.7 Read diagnostic and status information

34222

Diagnostic and status information is accessible via the following index groups:

Name (Index)	Description	Reference
MDP Standard Information (0x1000)	<ul style="list-style-type: none"> ▪ Device information via IO-Link master ▪ Identity Object ▪ Diagnostic history 	→ MDP Standard Information (0x1000) (→ S. 98)
IO Info Data (0x9000)	Information about IO-Link devices at IO-Link-Ports X01...X08	→ Port Mode (0x9000) (→ S. 103)
IO Diag Data (0xA000)	Diagnostic data of the IO-Link ports X01...X08	→ Diagnostics Data (0xA000) (→ S. 103)
Device Status (0xF000)	<ul style="list-style-type: none"> ▪ Status of the IO-Link devices at the IO-Link port X01...X08 ▪ Port qualifier 	→ Device Status / Port Status (0xF000) (→ S. 104)

When the IO-Link master is integrated into a EtherCAT project, TwinCAT automatically creates variables for diagnostic and status information in the Solution Explorer. They are grouped in folders under the device node. The user can link the variables directly with the elements of a global variable list (GVL).

The following variables are created:

Group > Variable	Description
[TxPDO IO-Link Device Status] > [State of IO-Link Ch.n]	Status of the IO-Link device at the IO-Link port X0n
[TxPDO IO-Link Port Qualifier] > [Qualifier of IO-Link Ch.n]	Port qualifier bits of the IO-Link port X0n
[TxPDO New Diagnosis Message available] > [New Message Available Flag]	Notification of new diagnostic messages

n ... 1...8

9.3.8 Read IO-Link events

33662

IO-Link Events will be stored in the "Diagnosis History" (→ **Diagnosis History (0x10F3)** (→ S. [107](#))).

The IO-Link Master stores a maximum of 64 events.

The single events will be stored in a ring buffer. The AL1332 supports the following operation modes for writing the ring buffer:

- **Overwrite Mode:** If the buffer memory is full, the oldest event will be overwritten by new incoming events.
- **Acknowledge Mode:** Events will only be overwritten, when they are read and acknowledged.

The configuration is done via sub-index 0x05. The events are stored in sub-indexes 0x06...0x46.

9.3.9 Configure IO-Link devices

33881

The IO-Link master supports the configuration of the connected IO-Link devices from the EtherCAT projection software. The parameters of an IO-Link device are set via IO-Link index and subindex. The number of the configurable parameters depends on the connected IO-Link device.



Available parameters of the IO-Link devices: → IO Device Description (IODD) of the IO-Link device

The user can read and write IO-Link index and subindex using the following methods:

- Acyclic communication: → **Use acyclic services** (→ S. [84](#))

9.3.10 EtherCAT: Programmers' notes

Content

Use acyclic services 84

33665

Use acyclic services

34187

The AL1332 supports following services for acyclic read and write processes:

- AoE - ADS over EtherCAT (→ **Use ADS over EtherCAT** (→ S. 84))
- CoE - CANopen over EtherCAT (→ **Use CANopen over EtherCAT** (→ S. 84))

Use ADS over EtherCAT

34190

AoE is suited for interruption-free access to the connected IO-Link devices during the operating time of the device. Access to the IO-Link master with AoE is not supported.



The function blocks for using AoE are part of the `tc2_system.libTwinCAT` library.

The following rules apply to the inputs of the ADS function blocks:

Input	Description	Possible values	
PORT	ADS communication port = 0x1000 + IO-Link port number	0x1001 0x1002 ... 0x1008	IO-Link port X01 IO-Link port X02 ... IO-Link port X08
IDXGRP	AoE index group	0xF302	
IDXOFFS	Index Offset		e. g. access to index 21, subindex 0: 0x0021°0x00°0x00
	Bits 0-7:	IO-Link subindex	
	Bits 8-15:	00000000	
	Bits 16-31:	IO-Link index	
ERRID	ADS error code		e. g. access to parameters of the IO-Link device refused: 0x0700°8023
	Bits 0-15:	Error code of the IO-Link device	
	Bits 16-31:	ADS device error = 0x0700	

Use CANopen over EtherCAT

34193

CoE is suited for acyclic access to the IO-Link master and the connected IO-Link devices. CoE uses the fieldbus objects "IO-Link acyclic command" (→ **IO-Link Acyclic Command (0x3100)** (→ S. 100)). A separate fieldbus object is provided for each IO-Link port.

To have acyclic access to the device via CoE the user can use the following function blocks:

- FB_EcCoESdoRead: read SDO of an EtherCAT slave
- FB_EcCoeSdoWrite: write SDO of an EtherCAT slave



The function blocks for using CoE are part of the `Tc2_EtherCAT.library` function library.

► Add `Tc2_EtherCAT.library` function block library to the project

Description of the function blocks: → Help function of TwinCAT

The following rules apply to the inputs of the CoE function blocks:

Input	Description	Possible values								
sNetId	AMS net ID of the EtherCAT master to which the IO-Link master is connected	depends on the project; e.g. 172.16.2.131.2.1								
nSlaveAddr	EtherCAT address of the IO-Link port on the IO-Link master = 0x1000 + IO-Link port number	<table border="1"> <tr> <td>0x1001</td> <td>IO-Link port X01</td> </tr> <tr> <td>0x1002</td> <td>IO-Link port X02</td> </tr> <tr> <td>...</td> <td>...</td> </tr> <tr> <td>0x1008</td> <td>IO-Link port X08</td> </tr> </table>	0x1001	IO-Link port X01	0x1002	IO-Link port X02	0x1008	IO-Link port X08
0x1001	IO-Link port X01									
0x1002	IO-Link port X02									
...	...									
0x1008	IO-Link port X08									
nSubIndex	IO-Link subindex of the parameter	depends on the device; → IODD								
nIndex	IO-Link index of the parameter	depends on the device; → IODD								

Principle of the acyclic command processing

34201

General processing of acyclic communication:

1 Write command request

- ▶ In the command buffer (0x310n:sub-index 0x01): write required request data.
- > Request data is transmitted.
- > Command processing is initiated.
- > Request channel is locked.

2 Check status

- ▶ In the status byte (0x310n:sub-index 0x02): read status information.
 - If status == 0xFF: command processing is pending, repeat step 2.
 - If status < 0xFF: command processing is finished, continue with step 3.

3 Read command response

- ▶ In the response buffer (0x310n:sub-index 0x03): read response data.
- > The request channel is unlocked.
- > Next command processing can be initiated.



The AL1332 can only process one CoE request at a time. If during an active request another CoE request is started, the device answers with an error (SDO abort code: 0x06090030).

10 Operation

Content

Using web-based management.....	86
---------------------------------	----

34061

10.1 Using web-based management

61181

The device has an integrated web server. The web server generates a website with the following data:

- Status information of the ports
- Access to product page of connected IO-Link devices (only ifm devices)
- Diagnostic information of the device
- Version information of the installed firmware components

To access the web interface of the IO-Link master:

- ▶ Connect the IO-Link master to the laptop / PC via the IoT port.
- ▶ Optional: Check the IP settings of the IoT interface.
- ▶ Start web browser.
- ▶ In the address field of the web browser, enter the IP address of the IoT interface and confirm with [ENTER].
- > The web browser shows the website with the status and diagnostic information of the device.

11 Maintenance, repair and disposal

Content

Cleaning process.....	87
Updating the firmware	87
Replacing IO-Link device.....	87

51990

The operation of the unit is maintenance-free.

- ▶ Dispose of the unit in an environmentally friendly way in accordance with the applicable national regulations when it is no longer used.

11.1 Cleaning process

51991

- ▶ Clean the surface of the unit when necessary.
- ▶ Do not use any caustic cleaning agents for this!
- ▶ In case of severe soiling, use a damp cloth.
- ▶ Do not use any caustic cleaning agents for this!

11.2 Updating the firmware

61183

The firmware of the IO-Link master can be updated via the IoT Core Visualizer → **Updating the firmware** (→ S. [78](#)).

11.3 Replacing IO-Link device

34182

To replace an IO-Link device:

Requirement:

- > New IO-Link device is with factory settings.
- > New IO-Link device supports IO-Link standard 1.1 or higher.

1 Set data storage

- ▶ Set the following parameters of the IO-Link port
 - Set Validation and Data Storage to [Type compatible V1.1 device with Restore] or [Type compatible V1.1. device with Backup + Restore]
 - Set correct values to [Vendor ID] and [Device ID] according to properties of the IO-Link device.
- ▶ Save changes.

2 Replace IO-Link device

- ▶ Disconnect old IO-Link device from IO-Link master.
- ▶ Connect new IO-Link device with the same IO-Link port of the AL1332.
- > IO-Link master copies parameter values from the data memory to the new IO-Link device.

12 Factory settings

33849

In the factory settings, the device has the following parameter settings:

Parameter	Factory setting
[IP address] (IoT interface)	169.254.X.X
[Subnet mask] (IoT interface)	255.255.0.0
[IP gateway address] (IoT interface)	0.0.0.0
[Host name]	blank
Data storage	empty

13 Accessories

33870

List of accessories of AL1332: → www.ifm.com > Product page > Accessories

14 Appendix

Content	
Technical data	91
EtherCAT	95
ifm IoT Core	111

33879

14.1 Technical data

Content

Application	91
Electrical data	91
Inputs / outputs	91
Inputs	92
Outputs	92
Interfaces	92
Operating conditions.....	93
Approvals / tests	93
Mechanical data	93
Electrical connection.....	94

34188

14.1.1 Application

33878

Application	
Application	I/O modules for field applications
Daisy-chain function	Fieldbus interface

14.1.2 Electrical data

33808

Electrical data	
Operating voltage [V]	20...30 DC; (US; to SELV/PELV)
Current Consumption [mA]	300...3900; (US)
Protection class	III
Sensor supply US	
Max. current load total [A]	3.6

14.1.3 Inputs / outputs

34068

Inputs / outputs	
Total number of inputs and outputs	16; (configurable)
Number of Inputs and Outputs	Number of digital inputs: 16; Number of digital outputs: 8

14.1.4 Inputs

34069

Inputs	
Number of digital inputs	16; (IO-Link Port Class A: 8 x 2)
Switching level high [V]	11...30
Switching level low [V]	0...5
Digital inputs protected against short circuits	yes

14.1.5 Outputs

34053

Outputs	
Number of digital outputs	8; (IO-Link Port Class A: 8 x 1)
Max. current load per output [mA]	300
Short-circuit protection	yes

14.1.6 Interfaces

34078

Interfaces	
Communication interface	Ethernet; IO-Link
Communication interface	IO-Link; TCP/IP; EtherCAT
Ethernet	
Transmission standard	10Base-T; 100Base-TX
Transmission rate [MBit/s]	10; 100
Protocol	EtherCAT, Zero config
Factory settings	MAC address: see type label
IO-Link master	
Type of transmission	COM 1 / COM 2 / COM 3
IO-Link revision	V1.1
Number of ports Class A	8
IoT interface	
Transmission standard	10Base-T; 100Base-TX
Transmission rate [MBit/s]	10; 100
Protocol	DCP, DHCP, Auto IP
Factory settings	<ul style="list-style-type: none"> ▪ IP address: 169.254.X.X ▪ Subnet mask: 255.255.0.0 ▪ Gateway IP address: 0.0.0.0 ▪ MAC address: see type label

14.1.7 Operating conditions

34062

Operating conditions	
Applications	Indoor use
Ambient temperature [°C]	-25...60
Storage temperature [°C]	-25...85
Max. perm. relative air humidity [%]	90
Max. height above sea level [m]	2000
Protection rating	IP 65; IP 66; IP 67
Pollution Degree	2

14.1.8 Approvals / tests

33877





Approval / tests	
EMC	<ul style="list-style-type: none"> ▪ EN 61000-6-2 ▪ EN 61000-6-4
MTTF [Years]	90

14.1.9 Mechanical data

34050

Mechanical data	
Weight [g]	404
Materials	Housing: PA; socket: brass nickel-plated

14.1.10 Electrical connection

Voltage supply IN X31											
Plug and socket connection	M12										
Wiring	 <table style="display: inline-table; vertical-align: middle;"> <tr><td>1:</td><td>+ 24 V DC (US)</td></tr> <tr><td>2:</td><td>-</td></tr> <tr><td>3:</td><td>GND (US)</td></tr> <tr><td>4:</td><td>-</td></tr> </table>	1:	+ 24 V DC (US)	2:	-	3:	GND (US)	4:	-		
1:	+ 24 V DC (US)										
2:	-										
3:	GND (US)										
4:	-										
Ethernet IN / OUT X21, X22											
Plug and socket connection	M12										
Wiring	 <table style="display: inline-table; vertical-align: middle;"> <tr><td>1:</td><td>TX +</td></tr> <tr><td>2:</td><td>RX +</td></tr> <tr><td>3:</td><td>TX -</td></tr> <tr><td>4:</td><td>RX -</td></tr> <tr><td>5:</td><td>-</td></tr> </table>	1:	TX +	2:	RX +	3:	TX -	4:	RX -	5:	-
1:	TX +										
2:	RX +										
3:	TX -										
4:	RX -										
5:	-										
IoT X23											
Plug and socket connection	M12										
Wiring	 <table style="display: inline-table; vertical-align: middle;"> <tr><td>1:</td><td>TX +</td></tr> <tr><td>2:</td><td>RX +</td></tr> <tr><td>3:</td><td>TX -</td></tr> <tr><td>4:</td><td>RX -</td></tr> <tr><td>5:</td><td>-</td></tr> </table>	1:	TX +	2:	RX +	3:	TX -	4:	RX -	5:	-
1:	TX +										
2:	RX +										
3:	TX -										
4:	RX -										
5:	-										
Process connection IO-Link ports Class A X01...X08											
Plug and socket connection	M12										
Wiring	 <table style="display: inline-table; vertical-align: middle;"> <tr><td>1:</td><td>Sensor supply (US) L+</td></tr> <tr><td>2:</td><td>DI</td></tr> <tr><td>3:</td><td>Sensor supply (US) L-</td></tr> <tr><td>4:</td><td>C/Q IO-Link</td></tr> <tr><td>5:</td><td>-</td></tr> </table>	1:	Sensor supply (US) L+	2:	DI	3:	Sensor supply (US) L-	4:	C/Q IO-Link	5:	-
1:	Sensor supply (US) L+										
2:	DI										
3:	Sensor supply (US) L-										
4:	C/Q IO-Link										
5:	-										

14.2 EtherCAT

Content	
Parameter data	96
Cyclic data	97
Acyclic data	98
Events	107

33674

14.2.1 Parameter data

Content

Fieldbus parameters	96
EtherCAT modules	96
ESI file	96

34170

Fieldbus parameters

33830

The fieldbus parameters contain information about the integration of the device into the EtherCAT network:

Name	Description	Possible values
EtherCAT address	"Explicit Device ID" of the device	0...65534

EtherCAT modules

33680

Module	Description	
IOL_In_4Byte	IO-Link activated	4-byte input data
IOL_In_8Byte		8-byte input data
IOL_In_16Byte		16-byte input data
IOL_In_32Byte		32-byte input data
IOL_Out_4Byte		4-byte output data
IOL_Out_8Byte		8-byte output data
IOL_Out_16Byte		16-byte output data
IOL_Out_32Byte		32-byte output data
IOL_4/4_I/O bytes		4-byte input data / 4-byte output data (default)
IOL_8/8_I/O bytes		8-byte input data / 8-byte output data
IOL_4/16_I/O bytes		4-byte input data / 16-byte output data
IOL_16/4_I/O bytes		16-byte input data / 4-byte output data
IOL_16/16_I/O bytes		16-byte input data / 16-byte output data
IOL_32/32_I/O bytes		32-byte input data / 32-byte output data
Digital_IN	IO-Link deactivated	Digital input
Digital_OUT		Digital output
Deactivated	deactivated	

ESI file

33810

To represent the AL1332 in a field bus projection software ifm electronic provides an ESI file. The EDS file can be downloaded from ifm's website. In the ESI file, all parameters, process data and their valid value ranges are defined.

14.2.2 Cyclic data

Content

Process Data Objects (PDO)	97
----------------------------------	----

33814

Process Data Objects (PDO)

34204

Selection of IO-Link Port via n (n = 0: Port X01, n = 1: Port X02,...)

Index	Name	Description	Data type / Access
0x1C12	RxPDO Assign	Outputs: List of references to RxPDO Mapping 0x160n; one subindex for each module	UINT16
0x1C13	TxPDO Assign	Inputs: List of references to TxPDO Mapping 0x1A0n; one subindex for each module	UINT16
0x160n	RxPDO Mapping	Outputs: List of references to RxPDO Data in Output Area; one index for each module; multiple subindices	UINT32 / rw
0x1A0n	TxPDO Mapping	Inputs: List of references to TxPDO Data in Input Area; one index for each module; multiple subindices	UINT32 / r
0x1A08	TxPDO Mapping of New Msg. Avail.	Inputs: Reference to TxPDO Data of New Message Available in 0x10F3:04 (1 bit) and 31 alignment bits	UINT32 / r
0x1A09	TxPDO Mapping of Timestamp	Inputs: Reference to TxPDO Data of Timestamp in 0x10F8 (64 bit)	UINT64 / r
0x1A81	TxPDO Mapping of Device Status	Inputs: References to TxPDO Data of Device Status in 0xF100:nn (8 bit), for all ports	UINT32 / r
0x1A82	TxPDO Mapping of Port Qualifier	Inputs: References to TxPDO Data of Port Qualifier in 0xF101:0n (8 bit), for all ports	UINT32 / r
0x70n0	Output Area, RxPDO Data	Outputs: RxPDOs (the cyclic data itself) of all modules; one index for each module; multiple subindices for multiple cyclic data objects	Octet String / rw
0x60n0	Input Area, TxPDO Data	Inputs: TxPDOs (the cyclic data itself) of all modules; one index for each module; multiple subindices for multiple cyclic data objects	Octet String / r
0x140n	RxPDO Parameter	Outputs: RxPDO Control for setting outputs valid/invalid; one index for each module; only subindex 8; unused here	Record / rw
0x180n	TxPDO Parameter	Inputs: TxPDO State for telling if inputs are valid/invalid; one index for each module; only subindex 7; unused here	Record / r
0xF100	Device Status	This status byte is included in input data of each module; one subindex for each module	UINT8 / r
0xF101	Port Qualifier	This status byte is included in input data of each module; one subindex for each module	UINT8 / r

14.2.3 Acyclic data

Content

Note	98
MDP Standard Information (0x1000).....	98
Manufacturer Specific Index (0x2000).....	99
IO-Link Acyclic Command (0x3100).....	100
IO-Link Inputs (0x6000).....	101
IO-Link Outputs (0x7000).....	101
Port Configuration (0x8000).....	102
Port Mode (0x9000).....	103
Diagnostics Data (0xA000).....	103
Device Status / Port Status (0xF000).....	104

33868

Note

34057

The device implements a "Modular Device Profile" with an "IO-Link profile" according to ETG.5001.1.

MDP Standard Information (0x1000)

34040

Identity information about the device and current and available process data constellations

Index	Sub-index	Description	Possible values / reference	Data type / Access
0x1000		Device Type	MDP Profile = 0x184C1389	UINT32 / r
0x1008		Manufacturer Device Name	"IO-Link Master DL EC 8P IP67"	STRING / r
0x1009		Manufacturer Hardware Version	z.B. "AA"	STRING / r
0x100A		Manufacturer Software Version		STRING / r
0x1018		Identity Object		
	0x1	Vendor ID	0x622	UINT32 / r
	0x2	Product Code	"AL1332"	UINT32 / r
	0x3	Revision Number:		UINT32 / r
	0x4	Serial Number		UINT32 / r
0x10F8		Timestamp (value in ns)		UINT64 / r

r ... read only

rw ... read and write

Manufacturer Specific Index (0x2000)

34036

Manufacturer-specific parameters

Index	Sub-index	Description	Possible values		Data type / Access
0x2001		Component Name	"EtherCAT IO-Link Gateway"		STRING / r
0x2002		Vendor Name	"ifm electronic"		STRING / r
0x2003		Vendor URL	"www.ifm.com"		STRING / r
0x2004		Order Number	"AL1332"		STRING / r
0x2005		Manufacturing Date			STRING / r
0x2006		QS Date			STRING / r
0x2007		Installation Location	user-defined; max. 20 characters		STRING / rw
0x200A		Equipment ID	user-defined; max. 20 characters		STRING / rw
0x2F00		Reset To Factory	0xA500:	Factory Reset of System + NVMEM	UINT16 / w
			0xA501:	Factory Reset of System	
0x2F01		Device Localization	0x00:	LED RDY blinking for 5 s	UINT8 / w
0x2F02		Current Use Case (Access Rights)	0xA500:	EtherCAT + IoT	UINT16 / rw
			0xA501:	EtherCAT + IoT (read only)	
			0xA502:	IoT (only)	

r ... read only
 rw ... read and write
 w ... write only

IO-Link Acyclic Command (0x3100)

33664

Selection of the IO-Link port via n (n = 0: port X01, n = 1: port X02,...)

Index	Sub-index	Description	Possible values	Data type / Access	
0x310n		IO-Link Acyclic Command			
	▪ 0x01	Command Buffer	Byte 0:	Command (0x0 = Read, 0x1 = Write)	ARRAY_OF_BYTE / rw
			Byte 1:	IO-Link Index, LSB	
			Byte 2:	IO-Link Index, MSB	
			Byte 3:	IO-Link Subindex	
			Byte 4:	For Write only: Length of following data (0x01...0xE8)	
			Byte 5:	For Write only: Data (0x00...0xE8)	
	▪ 0x02	Status	0x00:	Command completed: no error, no response data	UINT8 / r
			0x01:	Command completed: no error, response data available	
			0x02:	Command completed: error, no response data	
			0x03:	Command completed: error, response data available	
			0xFF:	Command is executing (pending)	
	▪ 0x03	Response Buffer	Byte 0:	Status (see Subindex 0x02)	ARRAY_OF_BYTE / r
			Byte 1:	reserved	
			Byte 2:	If status = 0x1 0x3: Length of the following data	
Byte 3..m:			If status = 0x1: Read data (0x00...0xE8) If status = 0x3: 1 byte IO-Link Error Code + 1 byte Additional Code		

r ... read only

rw ... read and write

IO-Link Inputs (0x6000)

33669

Input data of the IO-Link ports X01...X08

Selection of the IO-Link port via n (n = 0: port X01, n = 1: port X02,...)

Index	Sub-index	Description	Possible values	Data type / Access
0x60n0		IO-Link Inputs		
	▪ 0x01	Byte 1	je Byte: 0x00...0xFF	pro Byte: UINT8 / r
		
	▪ 0x20	Byte 32		

r ... read only

IO-Link Outputs (0x7000)

33667

Output data of the IO-Link ports X01...X08

Selection of the IO-Link port via n (n = 0: port X01, n = 1: port X02,...)

Index	Sub-index	Description	Possible values	Data type / Access
0x70n0		IO-Link Outputs		
	▪ 0x01	Byte 1	pro Byte: 0x00...0xFF	pro Byte: UINT8 / rw
		
	▪ 0x20	Byte 32		

rw ... read and write

Port Configuration (0x8000)

34214

Manufacturer-specific settings of the IO-Link ports X01...X08

Selection of the IO-Link port via n (n = 0: port X01, n = 1: port X02,...)

Index	Sub-index	Description	Possible values		Data type / Access
0x80n0		Port Configuration			
	▪ 0x04	Device ID	0x000000 ... 0xFFFFFFFF		UINT32 / rw
	▪ 0x05	Vendor ID	0x0000 ... 0xFFFF		UINT32 / rw
			0x136:	ifm electronic	
	▪ 0x20	IO-Link Revision	0x10:	IO-Link Revision 1.0	UINT8 / rw
			0x11:	IO-Link Revision 1.1	
	▪ 0x22	Cycle Time			UINT32 / rw
	▪ 0x24	Process Data In Length			UINT8 / rw
	▪ 0x25	Process Data Out Length			UINT8 / rw
	▪ 0x28	Master Control	0x00:	Deactivated	UINT16 / rw
0x01:			Digital Input		
0x02:			Digital Output		
0x03:			IO-Link		
0x80n8		Vendor Specific Port Configuration			
	▪ 0x01	Validation ID	0x00:	No check	UINT8 / rw
			0x01:	V1.0 Device, no DS	
			0x02:	V1.1 Device, no DS	
			0x03:	V1.1 Device, Backup + Restore	
			0x04:	V1.1 Device, Restore	
	▪ 0x02	Reconfigure	0x00:	No action	UINT8 / rw
			0xFF:	Activate configuration	
	▪ 0x03	Byte Swap	0x00:	No action	UINT8 / rw
			0x01:	Byte swap	

rw ... read and write

Port Mode (0x9000)

34213

Current value of the connected IO-Link devices

Selection of the IO-Link port via n (n = 0: port X01, n = 1: port X02,...)

Index	Sub-index	Description	Possible values	Data type / Access
0x90n0		Port Mode		
	▪ 0x04	Device ID		UINT32 / r
	▪ 0x05	Vendor ID		UINT32 / r
	▪ 0x20	IO-Link Revision		UINT8 / r
	▪ 0x21	Frame Capability		UINT8 / r
	▪ 0x22	Cycle Time		UINT8 / r
	▪ 0x24	PD In Length		UINT8 / r
	▪ 0x25	PD Out Length		UINT8 / r

r ... read only

Diagnostics Data (0xA000)

33821

The device provides the following diagnostic data for each port:

Selection of the IO-Link port via n (n = 0: port X01, n = 1: port X02,...)

Index	Sub-index	Description	Possible values	Data type / Access
0xA0n0		Diagnostics Data		
	▪ 0x01	IO-Link State	0x00: INACTIVE	UINT8 / r
			0x01: DIGINPUT	
			0x02: DIGOUTPUT	
			0x08: OPERATE	
			0x09: STOP	
▪ 0x02	▪ Subindex 0x02: Lost Frames		UINT8 / r	

r ... read only

Device Status / Port Status (0xF000)

33812

Status of the IO-Link device at the port X01...X08

Selection of the IO-Link port via n (n = 0: port X01, n = 1: port X02,...)

Index	Sub-index	Description	Possible values	Data type / Access
0xF000		Module Device Profile		
	▪ 0x01	▪ Module Index Distance	0x0010	UINT16 / r
	▪ 0x02	▪ Maximum number of modules	0x0008	UINT16 / r
0xF030		Configured Module Ident List		
0xF050		Detected Module Ident List		
0xF100		Device Status		UINT8 / r
	▪ 0x01	▪ IO-Link Port X01	→ Mapping: Device Status (0xF100) (→ S. 105)	
		
	▪ 0x0n	▪ IO-Link Port X08		
0xF101		IO-Link Port Qualifier		
	▪ 0x01	▪ PQI Port X01	→ Mapping: Port Qualifier (0xF101) (→ S. 106)	
		
	▪ 0x0n	▪ PQI Port X08		

r ... read only

Mapping: Device Status (0xF100)

34039

Bit							
7	6	5	4	3	2	1	0
Error Code				Port State			

Legend:

- [Error Code] Error code of the IO-Link Device
 - 0x0 No error
 - 0x3 Invalid Device ID
 - 0x4 Invalid Vendor ID
 - 0x7 Invalid cycle time
 - 0x8 Invalid length of PD In
 - 0x9 Invalid length of PD Out
 - 0xA No device detected
 - 0xB Supply voltage low or short circuit
 - 0xD Unspecified error
 - [Port State] State of the IO-Link port
 - 0x0 Deactivated
 - 0x1 Digital Input
 - 0x2 Digital Output
 - 0x3 OP: IO-Link, Operate state
 - 0x4 STOP: IO-Link, not Operate state (fault or no device)
 - 0x5 PreOP: IO-Link, device in PreOP state
- Note If more than one error occurs at the same time, only one error will be shown. The other error messages will be suppressed.

Mapping: Port Qualifier (0xF101)

34041

Port Qualifier Information (PQI) contains diagnostic information about the IO-Link port. In addition to the process data, the IO-Link master sends the PQI to the EtherCAT controller.

Bit							
7	6	5	4	3	2	1	0
PVI	PE	DA	DACT	PVO	--	DI2	DI4

Legend:

- [DI4] Signal status of the digital input on pin 4 (if used)

0x0	OFF
0x1	ON
- [DI2] Signal status of the digital input on pin 2 (if used)

0x0	OFF
0x1	ON
- [PVO] Port validity output: Validity of the output data of the IO-Link device

0x0	invalid
0x1	valid
- [DACT] Device deactivated: shows if the IO-Link port is configured and can be used

0x0	activated and can be used
0x1	deactivated or not available
- [DA] Device available: shows if the IO-Link device has been recognised and if the device is in the "preoperate" or in the "operate" state

0x0	No device
0x1	device detected
- [PE] Port error: shows if an error or a warning occurred (e.g. validation fault, short circuit); Note: The user needs to determine the cause of the fault separately via acyclic services.

0x0	no error
0x1	Error
- [PVI] Port validity input: Validity of the input data of the IO-Link device

0x0	invalid
0x1	valid

14.2.4 Events

Content

Diagnosis History (0x10F3)	107
----------------------------------	-----

33809

Diagnosis History (0x10F3)

33815

Index	Sub-index	Description	Possible values	Datentyp / Zugriff	
0x10F3		Diagnosis History			
	0x01	Maximum Messages	0x00...0x0x40	UINT8 / r	
	0x02	Newest Messages	0x00...0x0x40	UINT8 / r	
	0x03	Newest Ack. Message	Override Mode (Subindex 5, Bit 4 = 0):		UINT8 / rw
			0	Reading: When the message queue will be overwritten, the slave shall set Subindex 0x03 to 0 Writing: the slave will clear all messages, i.e. resetting Subindex 0x02, 0x03, 0x04 and 0x5/Bit 5	
			1...5	Writing: the slave shall return SDO-Abort with codes 0x06090030 (value range of parameter exceeded) or 0x0609003	
			6...0x46	Writing: Subindex 0x03 = Written value without checking	
			0x46...255	Writing: SDO-Abort with codes 0x06090030 or 0x06090031 (value of parameter written too high)	
			Acknowledge Mode (Subindex 5, Bit 4 = 1):		
			0	Read: No messages have been acknowledge so far Writing: All acknowledged messages will be deleted.	
			1...5	Writing: The slave shall return SDO-Abort with codes 0x06090030 (value range of parameter exceeded) or 0x06090032	
			6...0x46	Read: SubIndex of latest acknowledged diagnosis message Writing: Messages are acknowledged	
			0x46...255	Writing: SDO-Abort with codes 0x06090030 or 0x06090031 (value of parameter written too high)	
	0x04	New Message Available	Override Mode:		BOOL / r
			0x0	newest msg. was read	
			0x1	newest msg. was not read	
			Acknowledge Mode:		
0x0			no acknowledged message		
0x1			diagnosis message are available which can be acknowledged (Subindex 0x02<->Subindex 0x03)		
0x05	Flags	Bit 0:	Enable Emergency sending (according to ETG.1000-6)	UINT16 / rw	

Index	Sub-index	Description	Possible values	Datentyp / Zugriff																																								
			<table border="1"> <tr> <td>0</td> <td>default if device does not support Emergency sending</td> </tr> <tr> <td>1</td> <td>new diagnosis messages shall be sent as Emergency message</td> </tr> <tr> <td colspan="2">Bit 1: Disable info messages</td> </tr> <tr> <td>0</td> <td>Info messages are stored in the diagnosis message queue (default)</td> </tr> <tr> <td>1</td> <td>Info messages will not be stored in the diagnosis message queue</td> </tr> <tr> <td colspan="2">Bit 2: Disable warning messages</td> </tr> <tr> <td>0</td> <td>Warning messages are stored in the diagnosis message queue (default)</td> </tr> <tr> <td>1</td> <td>Warning messages will not be stored in the diagnosis message queue</td> </tr> <tr> <td colspan="2">Bit 3: Disable error messages</td> </tr> <tr> <td>0</td> <td>Error messages are stored in the message queue (default)</td> </tr> <tr> <td>1</td> <td>Error messages will not be stored in the diagnosis message queue</td> </tr> <tr> <td colspan="2">Bit 4: Mode selection for diagnosis history handling</td> </tr> <tr> <td>0</td> <td>Overwrite Mode</td> </tr> <tr> <td>1</td> <td>Acknowledge Mode</td> </tr> <tr> <td colspan="2">Bit 5: Overwrite/Discard Information</td> </tr> <tr> <td colspan="2">Overwrite Mode:</td> </tr> <tr> <td>1</td> <td>unacknowledged messages have been overwritten (=buffer overrun) (Subindex 0x03 is set to 0)</td> </tr> <tr> <td colspan="2">Acknowledge Mode:</td> </tr> <tr> <td>1</td> <td>message buffer is full with unacknowledged messages and a new message is discarded.</td> </tr> <tr> <td colspan="2">Bit 6...15 reserved</td> </tr> </table>	0	default if device does not support Emergency sending	1	new diagnosis messages shall be sent as Emergency message	Bit 1: Disable info messages		0	Info messages are stored in the diagnosis message queue (default)	1	Info messages will not be stored in the diagnosis message queue	Bit 2: Disable warning messages		0	Warning messages are stored in the diagnosis message queue (default)	1	Warning messages will not be stored in the diagnosis message queue	Bit 3: Disable error messages		0	Error messages are stored in the message queue (default)	1	Error messages will not be stored in the diagnosis message queue	Bit 4: Mode selection for diagnosis history handling		0	Overwrite Mode	1	Acknowledge Mode	Bit 5: Overwrite/Discard Information		Overwrite Mode:		1	unacknowledged messages have been overwritten (=buffer overrun) (Subindex 0x03 is set to 0)	Acknowledge Mode:		1	message buffer is full with unacknowledged messages and a new message is discarded.	Bit 6...15 reserved		
0	default if device does not support Emergency sending																																											
1	new diagnosis messages shall be sent as Emergency message																																											
Bit 1: Disable info messages																																												
0	Info messages are stored in the diagnosis message queue (default)																																											
1	Info messages will not be stored in the diagnosis message queue																																											
Bit 2: Disable warning messages																																												
0	Warning messages are stored in the diagnosis message queue (default)																																											
1	Warning messages will not be stored in the diagnosis message queue																																											
Bit 3: Disable error messages																																												
0	Error messages are stored in the message queue (default)																																											
1	Error messages will not be stored in the diagnosis message queue																																											
Bit 4: Mode selection for diagnosis history handling																																												
0	Overwrite Mode																																											
1	Acknowledge Mode																																											
Bit 5: Overwrite/Discard Information																																												
Overwrite Mode:																																												
1	unacknowledged messages have been overwritten (=buffer overrun) (Subindex 0x03 is set to 0)																																											
Acknowledge Mode:																																												
1	message buffer is full with unacknowledged messages and a new message is discarded.																																											
Bit 6...15 reserved																																												
	0x06	Diagnosis Message 01	<p>→Mapping: Diagnosis Message (→ S. 109)</p>	OCTET STRING / r																																								
	...																																											
	0x00x46	Diagnosis Message 64																																										

r ... read only
r/w ... read and write

Mapping: Diagnosis Message

SYS_OBJECTID>

Parameter	Content	Possible values		Data type / Access	
Diag Code	Diagnostic code	Bit 0...15:	0x0000 - 0xDFFF	not used	UINT32 / r
			0xE000 - 0xE7FF	Bit 16...31: Manufacturer specific	
			0xE800	Bit 16...31: Emergency Error Code from DS301 or DS4xxx	
			0xE801 - 0xEDFF	reserved	
			0xEE00 - 0xEFFF	Bit 16...31: Profile specific	
			0xF000 - 0xFF00	not used	
			0xFF01	New IO-Link Event <ul style="list-style-type: none"> ▪ Byte 1: IO-Link Port (0x00 = Port 01, ...) ▪ Byte 2: Event Qualifier ▪ Byte 3+4: Event Code ▪ Byte 5: unused 	
			0xFF02	Port Configuration has failed <ul style="list-style-type: none"> ▪ Byte 1...5: unused 	
			0xFF03	IO-Link Device Lost (disconnected) <ul style="list-style-type: none"> ▪ Byte 1: IO-Link Port (0x00 = Port 01, ...) 	
			0xFF04	IO-Link Device Fault (validation error or PD length mismatch) <ul style="list-style-type: none"> ▪ Byte 1: IO-Link Port (0x00 = Port 01, ...) 	
0xFF05	IO-Link Device Operating <ul style="list-style-type: none"> ▪ Byte 1: IO-Link Port (0x00 = Port 01, ...) ▪ Byte 2: Old status code ▪ Byte 3: Old info code ▪ Byte 4: New status code ▪ Byte 5: New info code 				
Flags	Event type	Bit 0...3:	0x00	Info message	UINT16 / r
			0x01	Warning message	
			0x02	Error message	
Text ID	Text ID as reference to Diagnosis text as defined in ESI file	0x0000	no Text ID	UINT16 / r	
		else	Text ID reference to ESI file		
Time Stamp	Time Stamp (value in ns)			UINT64 / r	
Flags Parameter 1	Data type Parameter 1	0x0005	UINT8	UINT16 / r	
Parameter 1	IO-Link Port	0x01	Port X01	UINT8 / r	
		0x02	Port X02		
			
		0x08	Port X08		

Parameter	Content	Possible values		Data type / Access	
Flags Parameter 2	Data type Parameter 2	0x0006	UINT16	UINT16 / r	
Parameter 2	Event Code	geräteabhängig (→ IODD-Beschreibung des IO-Link Devices)		UINT16 / r	
Flags Parameter 3	Data type Parameter 3	0x0005	UINT8	UINT16 / r	
Parameter 3	Event Qualifier	Bit 0..2:	0x1	PHL	UINT8 / r
			0x2	DL	
			0x3	AL	
			0x4	APPL	
		Bit 3:	0x0	Source: Device	
			0x1	Source: Master	
		Bit 4...5:	0x1	Event Type: Info Message	
			0x2	Event Type: Warning Message	
			0x3	Event Error Message	
		Bit 6...7:	0x1	Message Type: Single	
			0x2	Message Type: Going	
			0x3	Message TYpe: Coming	

r ... read only

rw ... read and write

14.3 ifm IoT Core

Content	
Overview: IoT profile.....	112
Overview: IoT types.....	119
Overview: IoT services	120

33803

14.3.1 Overview: IoT profile

Content

Profile: blob	112
Profile: deviceinfo	113
Profile: devicetag	113
Profile: iolinkdevice_full	114
Profile: iolinkmaster	114
Profile: mqttCmdChannel	115
Profile: mqttCmdChannelSetup	115
Profile: mqttConnection	115
Profile: mqttSetup	116
Profile: network	116
Profile: parameter	117
Profile: processdata	117
Profile: runcontrol	117
Profile: service	117
Profile: software	117
Profile: software/uploadedablessoftware	118
Profile: Timer	118

34054

Profile: blob

52264

Element (identifier)	Properties	Mandatory	Comment
blobname	<ul style="list-style-type: none"> ▪ type = data ▪ profiles = blob 		labels element as device information
../size	type = data	mandatory	
../chunksize	type = data	mandatory	
../setblobdata	type = service	optional	
../getblobdata	type = service	optional	
../start_stream_set	type = service	optional	
../stream_set	type = service	optional	
../clear	type = service	optional	
../getcrc	type = service	optional	
../getmd5	type = service	optional	
../getdata	type = service	optional	
../setdata	type = service	optional	

Profile: deviceinfo

34207

Element (identifier)	Properties	mandatory	Comments
deviceinfo	<ul style="list-style-type: none"> ▪ type = structure ▪ profile = deviceinfo 		characterises the element as device information
../devicename	type = data	optional	
../devicefamily	type = data	optional	
../devicevariant	type = data	optional	
../devicesymbol	type = data	optional	
../deviceicon	type = data	optional	
../serialnumber	type = data	mandatory	
../productid	type = data	optional	
../productname	type = data	optional	
../productcode	type = data	mandatory	
../producttext	type = data	optional	
../ordernumber	type = data	optional	
../productiondate	type = data	optional	
../productioncode	type = data	optional	
../hwrevision	type = data	mandatory	
../swrevision	type = data	mandatory	
../bootloaderrevision	type = data	optional	
../vendor	type = data	optional	
../vendortext	type = data	optional	
../vendorurl	type = data	optional	
../vendorlogo	type = data	optional	
../productwebsite	type = data	optional	
../supportcontact	type = data	optional	
../icon	type = data	optional	
../image	type = data	optional	
../standards	type = data	optional	

Profile: devicetag

34206

Element (identifier)	Properties	mandatory	Comments
devicetag	<ul style="list-style-type: none"> ▪ type = structure ▪ profile = devicetag 		
../applicationtag	type = data	mandatory	
../applicationgroup	type = data	optional	
../machinecode	type = data	optional	
../tenant	type = data	optional	

Profile: iolinkdevice_full

52265

Element (identifier)	Characteristics	Mandatory	Comments
iolinkdevice	<ul style="list-style-type: none"> ▪ type = structure ▪ profile = iolinkdevice_full 		Structure of an IO-Link device
../vendorid	type = data	mandatory	
../deviceid	type = data	mandatory	
../productname	type = data	mandatory	
../serial	type = data	mandatory	
../applicationspecifictag	type = data	mandatory	
../pdin	type = data	mandatory	
../pdout	type = data	mandatory	
../status	type = data	mandatory	
../iolreadacyclic	type = data	mandatory	
../iolwriteacyclic	type = data	mandatory	
../iolinkevent	type = data	mandatory	

Profile: iolinkmaster

34205

Element (identifier)	Properties	Mandatory	Comments
masterport	<ul style="list-style-type: none"> ▪ type = structure ▪ profile = iolinkmaster 		Executable service
../mode	<ul style="list-style-type: none"> ▪ type = data ▪ profile = parameter 	mandatory	
../comspeed	<ul style="list-style-type: none"> ▪ type = data ▪ profile = parameter 	mandatory	
../mastercycletime_actual	<ul style="list-style-type: none"> ▪ type = data ▪ profile = parameter 	mandatory	
../mastercycletime_preset	<ul style="list-style-type: none"> ▪ type = data ▪ profile = parameter 	mandatory	
../validation_datastorage_mode	<ul style="list-style-type: none"> ▪ type = data ▪ profile = parameter 	mandatory	
../validation_vendorid	<ul style="list-style-type: none"> ▪ type = data ▪ profile = parameter 	mandatory	
../validation_deviceid	<ul style="list-style-type: none"> ▪ type = data ▪ profile = parameter 	mandatory	
../additionalpins_in	<ul style="list-style-type: none"> ▪ type = data ▪ profile = processdata 	optional	
../additionalpins_out	<ul style="list-style-type: none"> ▪ type = data ▪ profile = processdata 	optional	
../portevent	<ul style="list-style-type: none"> ▪ type = data 	mandatory	
../iolinkdevice	<ul style="list-style-type: none"> ▪ type = structure ▪ profile = iolinkdevice_full 	mandatory	

Profile: mqttCmdChannel

61186

Element (identifier)	Properties	Mandatory	Comment
mqttCmdChannel	<ul style="list-style-type: none"> ▪ type = structure ▪ profile = commChannel 		Profile of the MQTT command channel
../type	<ul style="list-style-type: none"> ▪ type = data ▪ data type = STRING 	mandatory	Protocol type of the interface
../status	<ul style="list-style-type: none"> ▪ type = data ▪ data type = STRING 	mandatory	Status of the MQTT command channel (possible values: init, running, stopped, error)
../mqttCmdChannelSetup	type = profile		Sub-profile: Profile: mqttCmdChannelSetup (→ S. 115)

Profile: mqttCmdChannelSetup

61187

Element (identifier)	Properties	Mandatory	Comment
mqttCmdChannelSetup	<ul style="list-style-type: none"> ▪ type = structure ▪ profile = mqttCmdChannelSetup 		Settings of the MQTT command channel
../brokerIP	<ul style="list-style-type: none"> ▪ type = data ▪ data type = STRING 	optional	
../brokerPort	<ul style="list-style-type: none"> ▪ type = data ▪ data type = STRING 	optional	
../cmdTopic	<ul style="list-style-type: none"> ▪ type = data ▪ data type = STRING 	optional	
../defaultReplyTopic	<ul style="list-style-type: none"> ▪ type = data ▪ data type = STRING 	optional	

Profile: mqttConnection

61188

Element (identifier)	Properties	Mandatory	Comment
mqttConnection	<ul style="list-style-type: none"> ▪ type = structure ▪ profile = commInterface 		MQTT connection in the IoT Core
../type	<ul style="list-style-type: none"> ▪ type = data ▪ data type = STRING 	mandatory	Protocol type of the interface
../status	<ul style="list-style-type: none"> ▪ type = data ▪ data type = STRING 	mandatory	global status of the MQTT (possible values: init, running, stopped, error)
../mqttSetup	type = profile		Sub-profile: Profile: mqttSetup (→ S. 116)
../mqttCmdChannel	type = profile		Sub-profile: Profile: mqttCmdChannel (→ S. 115)

Profile: mqttSetup

61189

Element (identifier)	Properties	Mandatory	Comment
mqttSetup	<ul style="list-style-type: none"> ▪ type = structure ▪ profile = mqttSetup 		Settings of the MQTT command channel
../QoS	<ul style="list-style-type: none"> ▪ type = data ▪ data type = Number 	mandatory	Quality of Service of the MQTT connection
../version	<ul style="list-style-type: none"> ▪ type = data ▪ data type = STRING 	mandatory	

Profile: network

52266

Element (identifier)	Characteristics	Mandatory	Comments
network	<ul style="list-style-type: none"> ▪ type = structure ▪ profiles = deviceinfo 		Characterises the element as device information
../macaddress	<ul style="list-style-type: none"> ▪ type = data ▪ profile = parameter 	mandatory	
../ipaddress	<ul style="list-style-type: none"> ▪ type = data ▪ profile = parameter 	optional	
../ipv6address	<ul style="list-style-type: none"> ▪ type = data ▪ profile = parameter 	mandatory	
../subnetmask	<ul style="list-style-type: none"> ▪ type = data ▪ profile = parameter 	mandatory	
../ipdefaultgateway	<ul style="list-style-type: none"> ▪ type = data ▪ profile = parameter 	mandatory	
../dhcp	<ul style="list-style-type: none"> ▪ type = data ▪ profile = parameter 	optional	
../ipversion	<ul style="list-style-type: none"> ▪ type = data ▪ profile = parameter 	optional	
../hostname	<ul style="list-style-type: none"> ▪ type = data ▪ profile = parameter 	optional	
../autonegotiation	<ul style="list-style-type: none"> ▪ type = data ▪ profile = parameter 	optional	
../portspeed	<ul style="list-style-type: none"> ▪ type = data ▪ profile = parameter 	optional	
../enablenetwork	type = service	optional	
../disablenetwork	type = service	optional	

Profile: parameter

34215

The profile is used to mark the elements of type data as parameters (acyclic data). The profile defines no substructure.

Profile: processdata

34225

The profile is used to mark the elements of type data as process data (cyclic data). The profile does not define a substructure.

Profile: runcontrol

61190

Element (identifier)	Properties	Mandatory	Comment
runcontrol	<ul style="list-style-type: none"> ▪ type = profile ▪ profile = runcontrol 		Control of the MQTT command channel
../start	type = service	mandatory	Service: start (→ S. 131)
../stop	type = service	mandatory	Service: stop (→ S. 131)
../reset	type = service	mandatory	Service: Reset (→ S. 128)

Profile: service

34224

Element (identifier)	Properties	mandatory	Comments
service	<ul style="list-style-type: none"> ▪ type = service ▪ profile = service 		Executable service

Profile: software

34223

Element (identifier)	Properties	mandatory	Comments
software	<ul style="list-style-type: none"> ▪ type = structure ▪ profile = software 		characterises the element as software
../version	type = data	mandatory	
../type	type = data	mandatory	
../status	type = structure	optional	
../diag	type = structure	optional	

Profile: software/uploadedablesoftware

52267

Element (identifier)	Characteristics	Mandatory	Comments
software	<ul style="list-style-type: none"> ▪ type = structure ▪ profiles = software/uploadablesoftware 		Software that can be loaded to the device via the IoT Core
../lastinstall	type = data	optional	
../installhistory	type = data	optional	
../container	<ul style="list-style-type: none"> ▪ type = data ▪ profile = blob 	mandatory	
../preinstall	type = service	optional	
../install	type = service	mandatory	
../postinstall	type = service	optional	
../abortinstall	type = service	optional	
../installstatus	type = data	optional	

Profile: Timer

34226

Element (identifier)	Properties	Mandatory	Comment
timer	<ul style="list-style-type: none"> ▪ type = structure ▪ profile = timer 		
../counter	<ul style="list-style-type: none"> ▪ type = data ▪ profile = parameter 	mandatory	
../interval	<ul style="list-style-type: none"> ▪ type = data ▪ profile = parameter 	optional	
../start	type = service	optional	
../stop	type = service	optional	

14.3.2 Overview: IoT types

34055

The ifm IoT Core uses the following element types:

Name	Description
structure	Element is a structure element (like a folder in a file system)
service	Element is a service that can be addressed from the network
event	Element is an event that can be started by the firmware and sends messages.
data	Element is a data point
device	Root element a device represents

14.3.3 Overview: IoT services

Content

Service: factoryreset	120
Service: getblobdata	121
Service: getdata	121
Service: getdatamulti	122
Service: getelementinfo	122
Service: getidentity	123
Service: getssubscriberlist.....	124
Service: getssubscriptioninfo.....	125
Service: gettree	126
Service: install	127
Service: iolreadacyclic	127
Service: iolwriteacyclic.....	127
Service: querytree	128
Service: reboot	128
Service: Reset	128
Service: setblock	129
Service: setdata	130
Service: signal	130
Service: start	131
Service: start_stream_set.....	131
Service: stop	131
Service: stream_set	132
Service: subscribe	132
Service: unsubscribe	134
Service: validation_useconnecteddevice	134

34056

Service: factoryreset

34184

Name: factoryreset

Description: The service sets the parameters of the device to the factory settings.

Request data (field "data"): none

Response data (field "data"): none

Example:

```
{
"code": "request",
"cid": 4711,
"adr": "/firmware/factoryreset"
}
```

Service: getblobdata

52345

Name: getblobdata**Description:** The service reads a binary large object (blob).**Applicable to:** datastorage**Request data (field "data"):**

Data field	Required field	Data type	Default	Description
pos	mandatory	number	0	Byte position
length	mandatory	number	-	Size of the object (number of bytes)

Return data (field "data"):

Data field	Required field	Data type	Default	Description
data	mandatory	STRING	0	Data to be decoded (BASE64 coded)
crc	optional	HEX STRING		CRC of the data after decoding
md5	optional	HEX STRING		MD5 checksum of the data after decoding

Service: getdata

34183

Name: getdata**Description:** Service reads the value of a data point and provides it.**Request data (field "data"):** none**Return data (field "data"):**

Data field	Required field	Data type	Description
value	mandatory	STRING	Value of the element/data point

Example:

```
{
  "code": "request",
  "cid": 4711,
  "adr": "devicetag/applicationtag/getdata"
}
```

Service: getdatamulti

34174

Name: getdatamulti**Description:** The service sequentially reads the values of several data points and provides them. The value and the diagnostic code are provided for each data point.**Request data (field "data"):**

Data field	Required field	Data type	Description
datatosend	mandatory	ARRAY OF STRINGS	List of data points to be requested; data points must support the service getdata ("datatosend":["url1","url2",..., "urlx"])

Response data (field "data"): for each requested data point

Data field	Required field	Data type	Description
url	mandatory	STRING	Data point request
code	mandatory	INT	Diagnostic code of the request
data	mandatory	STRING	Value of the data point

Service: getelementinfo

52269

Name: getelementinfo**Description:** The service reads the properties of an element of the IoT tree.**Applicable to:** Objects of the type device**Request data (field "data"):**

Data field	Required field	Data type	Default	Description
adr	mandatory	STRING		URL of the element, which properties to be changed

Return data (field "data"):

Data field	Required field	Data type	Default	Description
identifier	mandatory	STRING		Identifier of the element
type	mandatory	STRING		Type of the element
format	optional	JSON object	blank	Format of the data or the service content
uid	optional	STRING	blank	
profiles	optional	JSON array	blank	
hash	optional	STRING	--	

Service: getidentity

54690

Name: getidentity**Description:** The service reads the device information of the AL1332 and issues it.**Request data ("data" field):** none**Return data ("data" field):**

Data field	Required field	Data type	Description
iot		Device	Device description as JSON object
iot.name	mandatory	STRING	
iot.uid	optional	STRING	
iot.version	mandatory	STRING	
iot.catalogue	optional	ARRAY OF OBJECTS	
iot.deviceclass	optional	ARRAY OF STRING	
iot.serverlist	optional	ARRAY OF OBJECTS	
device	optional		AL1332
device.serialnumber	optional		Serial number
device.hwrevision	optional		Hardware version
device.swrevision	optional		Software version
device.custom	optional		
Security	optional		Security options
security.securitymode	optional	ENUM	shows if the security mode is activated
security.authscheme	optional	ENUM	shows the active authentication scheme
security.ispasswordset	optional	BOOL	shows whether a password has been set
security.activeconnection	optional	ENUM	shows the currently used communication interface <ul style="list-style-type: none"> ▪ tcp_if unencrypted http connection at the IoT interface, port 80 ▪ tls_if encrypted https connection at the IoT interface, port 443 ▪ fb_if unencrypted http connection at the fieldbus interface, port 80

Service: getsubscriberlist

61191

Name: getsubscriberlist**Description:** The service provides a list of all active subscriptions.**Request data ("data" field):** none**Return data ("data" field):** Array with the following data

Data field	Mandatory field	Data type	Description
adr	mandatory	STRING	Data source
datatosend	mandatory	ARRAY OF STRINGS	List with URLs of the subscribed data points
cid	mandatory	NUMBER	ID of the subscription
callbackurl	mandatory	STRING	Address to which IoT Core event notifications are to be sent;
duration	mandatory	STRING	Storage duration of the value

Example:

- **Request object:**

```
{
  "code": "request",
  "cid": 4711,
  "adr": "/getsubscriberlist"
}
```

- **Return object:**

```
{
  "cid": 4711,
  "data": [
    {
      "adr": "/timer[1]/counter/datachanged/subscribe",
      "datatosend": ["/iolinkmaster/port[2]/iolinkdevice/pdin"],
      "cid": 1,
      "callbackurl": "http://192.168.0.45:80/temp",
      "duration": "lifetime"
    },
    {
      "adr": "/timer[1]/counter/datachanged/subscribe",
      "datatosend": ["/processdatamaster/temperature", "/processdatamaster/voltage"],
      "cid": 2,
      "callbackurl": "http://192.168.0.44:80/temp",
      "duration": "lifetime"
    }
  ]
  "code": 200
}
```

Service: getsubscriptioninfo

61192

Name: getsubscriptioninfo**Description:** The service provides information about an existing subscription (subscribe).

The following parameters of the existing subscription are to be used for the query:

- Value of the identifier cid (e.g. 4711)
- Number of the timer (e.g. timer[1])
- Name of the callback topic (e.g. B. temp)

Request data ("data" field):

Data field	Mandatory field	Data type	Description
callback	mandatory	STRING	Address to which IoT Core event notifications are to be sent; complete URL: http://ipaddress:port/path

Return data ("data" field):

Data field	Mandatory field	Data type	Description
subscription	mandatory	BOOL	Status of the transferred subscription parameter
datatosend	mandatory	ARRAY OF STRINGS	List with subscribed data points
cid	mandatory	NUMBER	ID of the subscribe request
callbackurl	mandatory	STRING	Address to which IoT Core event notifications are to be sent; complete URL: http://ipaddress:port/path

Example:

- **Request object:**

```
{
  "code": "request",
  "cid": 4711,
  "adr": "/timer[1]/counter/datachanged/getsubscriptioninfo",
  "data": {
    "callback": "http://192.168.0.44:80/temp"
  }
}
```

- **Return object:**

```
{
  "cid": 4711,
  "data": {
    "subscription": true,
    "datatosend": [
      "/iolinkmaster/port[2]/iolinkdevice/productname",
      "/iolinkmaster/port[2]/iolinkdevice/pdin",
      "/processdatamaster/temperature"
    ],
    "callbackurl": "http://192.168.0.44:80/temp",
    "duration": "lifetime"
  },
  "code": 200
}
```

Service: gettree

61193

Name: gettree**Description:** The service reads the device description of the IO-Link master and outputs it as a JSON object. The output can be limited to a subtree of the device description.**Request data ("data" field):**

Data field	Mandatory field	Data type	Description
adr	optional	STRING	Root element of the subtree
level	optional	STRING	max. level up to which the subtree is output <ul style="list-style-type: none"> ▪ no entry: all levels will be displayed ▪ 0: do not display sub-elements ("subs") ▪ 1: display sub-elements ▪ 2: display sub-elements up to the 2nd level ▪ 3: display sub-elements up to the 3rd level ... ▪ 20: display sub-elements up to the 20th level

Return data ("data" field):

Data field	Mandatory field	Data type	Description
identifier	mandatory	STRING	Identifier of the root element
type	mandatory	STRING	Type of the element
format	optional	JSON Object	Format of the data content
uid	optional	STRING	
profiles	optional	JSON-Array	
subs	mandatory	JSON-Array	Sub-elements
hash	optional	STRING	

Examples:

- output the complete device description

```
{
"code": "request",
"cid": 4,
"adr": "/gettree"
}
```

- output the subtree counter[2] of the device description up to the 2nd level

```
{
"code": "request",
"cid": 4,
"adr": "/gettree"
"data": {
"adr": "counter[2]",
"level": 2}
}
```

Service: install

52343

Name: install**Description:** The service installs the firmware stored in the container area of the device.**Applicable to:** container**Request data (data):** none**Return data (data):** none**Service: iolreadacyclic**

34178

Name: iolreadacyclic**Description:** The service acyclically reads the parameter value of an IO-Link device. The parameter is accessed via IO-Link index and subindex.**Request data (field "data"):**

Data field	Required field	Data type	Description
index	mandatory	NUMBER	IO-Link index of the parameter
subindex	mandatory	NUMBER	IO-Link subindex of the parameter

Response data (field "data"):

Data field	Required field	Data type	Description
value	mandatory	STRING	Value of the parameter; Value in hexadecimal format

Service: iolwriteacyclic

34177

Name: iolwriteacyclic**Description:** The service acyclically writes the parameter value of an IO-Link device. The parameter is accessed via IO-Link index and subindex.**Request data (field "data"):**

Data field	Required field	Data type	Description
index	mandatory	NUMBER	IO-Link index of the parameter
subindex	mandatory	NUMBER	IO-Link subindex of the parameter
value	mandatory	STRING	New value of the parameter; Value in hexadecimal format

Response data (field "data"): none

Service: querytree

61194

Name: querytree**Description:** The service searches a device tree for the criteria profile, type and name and outputs a list with the URLs of the elements found. At least one of the search criteria must be specified. The service can only be executed on the root node of the machine.**Return data ("data" field):**

Data field	Mandatory field	Data type	Description
profile	optional	STRING	Profile of the searched element
type	optional	STRING	Type of the searched element
name	optional	STRING	Type of the searched element

Return ("data" field):

Data field	Mandatory field	Data type	Description
urlList	mandatory	Array	Array with URLs of the found elements; URLs are separated by commas

Service: reboot

34176

Name: reboot**Description:** The service reboots the device.**Request data (field "data"):** none**Return data (field "data"):** none**Example:**

```
{
  "code": "request",
  "cid": 4,
  "adr": "firmware/reboot"
}
```

Service: Reset

61195

Name: Reset**Description:** The service resets a connection to the initialisation state.**Request data ("data" field):** none**Return data ("data" field):** none**Example:**

```
{
  "code": "request",
  "cid": 4711,
  "adr": "/connections/mqttConnection/MQTTSetup/mqttCmdChannel/status/reset"
}
```

Service: setblock

34186

Name: setblock**Description:** The service simultaneously sets the values of several data points of a structure.**Request data (field "data"):**

Data field	Required field	Data type	Description
datatoset	mandatory	ARRAY OF OBJECTS	List of data points and their new values; data points must support the service setdata
consistent	optional	BOOL	

Response data (field "data"): none

Example:

Request:

```
{
"code": "request",
"cid": 4711,
"adr": "iotsetup/network/setblock",
"data": {
"datatoset": {
"ipaddress": "192.168.0.6",
"subnetmask": "255.255.255.0",
"ipdefaultgateway": "192.168.0.250",
"dhcp": 0}
}
}
```

Response:

```
{
"cid": 4711,
"code": 233
}
```

Service: setdata

34195

Name: setdata**Description:** The service sets the value of the data point.**Request data ("data" field):**

Data field	Mandatory field	Data type	Description
newvalue	mandatory	STRING	New value of the element/data point
duration	mandatory	STRING	Duration of value storage <ul style="list-style-type: none"> ▪ lifetime: Value is saved with IoT Core; Value remains valid even after restart of the device ▪ uptime: Value is saved until the next restart of the device

Return data ("data" field): none

Example:

```
{
  "code": "request",
  "cid": 4711,
  "adr": "devicetag/applicationtag/setdata",
  "data": {
    "newvalue": "ifm IO-Link master",
    "duration": "lifetime"
  }
}
```

Service: signal

33819

Name: signal**Description:** The service starts the flashing of the status LEDs of the AL1332.**Request data (field "data"):** none**Return data (field "data"):** none

Example:

```
{
  "code": "request",
  "cid": 4711,
  "adr": "firmware/signal"
}
```

Service: start

61196

Name: start**Description:** The service starts a connection.**Request data ("data" field):** none**Return data ("data" field):** none

Example:

```
{
  "code": "request",
  "cid": 4711,
  "adr": "/connections/mqttConnection/MQTTSetup/mqttCmdChannel/status/start"
}
```

Service: start_stream_set

52342

Name: start_stream_set**Description:** The service starts the sequential transfer of multiple data segments.**Applicable to:** Objects of type data**Request data (data):**

Data field	Required field	Data type	Default	Description
size	mandatory	STRING		Total size of data to be transferred (number of bytes)

Return data (data): none**Service: stop**

61197

Name: stop**Description:** The service stops a connection.**Request data ("data" field):** none**Return data ("data" field):** none

Example:

```
{
  "code": "request",
  "cid": 4711,
  "adr": "/connections/mqttConnection/MQTTSetup/mqttCmdChannel/status/stop"
}
```

Service: stream_set

52341

Name: stream_set**Description:** The service transfers a data segment.**Applicable to:** Objects of type data**Request data (data):**

Data field	Required field	Data type	Default	Description
value	mandatory	BIN (BASE64)	*	Segment of binary data (BASE64 coded)

Return data (data): none**Service: subscribe**

61198

Name: subscribe**Description:** The service subscribes to the values of data points. The data points to be subscribed are transferred as a list. The IoT Core sends changes to the data sink defined in callback.

CSV formatted notifications can only be transmitted using the TCP protocol via an activated and configured MQTT channel.

Request data ("data" field):

Data field	Mandatory field	Data type	Description
callback	mandatory	STRING	Address to which IoT Core event notifications are to be sent; URL format: <ul style="list-style-type: none"> JSON: http://ipaddress:port/path JSON: ws://path JSON: mqtt://ipaddress:port/topic CSV: tcp://ipaddress:port/path
datatosend	mandatory	ARRAY OF STRINGS	List from URLs of data elements; Elements must support getdata
codec	optional	STRING	Format of the returned data <ul style="list-style-type: none"> json: JSON formatted csv: CSV with standard separator (,) csv0: CSV formatted with comma separator (,) csv1: CSV formatted with semicolon separator (;)
DURATION	mandatory	STRING	Duration of value storage <ul style="list-style-type: none"> lifetime: Value is saved with IoT Core; Value remains valid even after restart of the device uptime: Value is saved until the next restart of the device once: send only one notification, user must unsubscribe immediately

Return data ("data" field): none**Notification:** JSON

```
{
"code": "event",
"cid": 4711,
"adr": "",
"data": {
```

```
"eventno": "EventNo",
"srcurl": "SrcURL",
"payload": {
  "eventurl": {"code": "EventStatus", "data": "EventData"},
  "datapointurl_1": {"code": "DataStatus_1", "data": "DataValue_1"},
  "datapointurl_2": {"code": "DataStatus_2", "data": "DataValue_2"},
  ...}}
}
```

Notification: CSV

SrcURL, EventNo, EventStatus, EventData, DataStatus_1, DataValue_1, DataStatus_2, DataValue_2, ...

- SrcURL: Source of the event (data point on which subscribe command was listed)
- EventNo: Event number
- EventStatus: Status code of the event
- EventData: Event data
- DataStatus_1: Status code of the 1st element in list datatosend
- DataValue_1: Value of the 1st element in list datatosend
- DataStatus_2: Status code of the 2nd element in list datatosend
- DataValue_2: Value of the 2nd element in list datatosend
- ...

Service: unsubscribe

34197

Name: unsubscribe

Description: The service deletes an existing subscription. The service unsubscribe is successful if cid and the callback address are registered for an active subscription (subscribe). If the STRING "DELETE" is provided in callback, the IO-Link master deletes all active subscriptions.

Request data (field "data"):

Data field	Required field	Data type	Description
callback	mandatory	STRING	Address to which IoT Core event notifications are to be sent; complete URL: http://ipaddress:port/path

Response data (field "data"): none

Service: validation_useconnecteddevice

52340

Name: validation_connecteddevice

Description: The service checks, whether Device ID and Vendor ID of the connected IO-Link device match with the values of the datapoints ../validation_vendorid and ../validation_deviceid.

Applicable to: Objects of type stucture

Request data (data): none

Return data (data): none

15 Index

A

Access the ifm IoT Core	37
Accessories	89
Acyclic data.....	98
Appendix.....	90
Application	91
Approvals / tests	93

C

Change history.....	6
Cleaning process.....	87
Communication, parameter setting, evaluation.....	11
Configuration	24
Configure cyclic process data.....	80
Configure IO-Link devices	34, 83
Configure IO-Link master	80
Configure IO-Link ports	80
Configuring IO-Link the master	76
Configuring the MQTT command channel	68
Connecting IO-Link devices for Class A operation	16
Connecting IO-Link devices for Class B operation	17
Connecting the device	18
Connecting the EtherCAT ports	15
Connecting the IoT port.....	15
Creating a new notification	73
Cyclic data	97

D

Deleting a notification	74
Device Status / Port Status (0xF000).....	104
Diagnosis History (0x10F3)	107
Diagnostics Data (0xA000).....	103
Digital inputs	12
DNS support	44

E

Electrical connection.....	14, 94
Electrical data	91
ESI file.....	96
EtherCAT	11, 79, 95
Programmers' notes	84
EtherCAT interface	21
EtherCAT modules	96
Events	107
Example	
Activate security mode	48
Browsing device description	43
Change name of the IO-Link master	61
Change the parameter value of an IO-Link device.....	57
Changing a subscription.....	63
Checking subscriptions	65
Clone the Data Storage of an IO-Link port	51
Configuring the MQTT command channel	70
GET request	37
output subtree	42
POST request.....	38
Publish the temperature to an MQTT broker	71
Read IO-Link process data (operating mode	53

Read several parameter values of the IO-Link master simultaneously	43
Read the parameter value of an IO-Link device.....	56
Reading digital input (operating mode	55
Reading properties of an element.....	41
Request with authentication	48
reset password	49
Subscribing notifications via WebSocket.....	66
Subscribing to notifications	45, 62
Subscribing to notifications in CSV format	64
Unsubscribing from notifications	64
Update firmware	60
Using DNS support.....	44
Writing digital output (operating mode	54
Writing IO-Link value (operating mode	54
Explanation of Symbols	5

F

Factory settings	88
Fail-safe values of the IO-Link ports.....	26
Fieldbus	
Configure EtherCAT interface.....	29
Configuring the fieldbus interface	50
Fieldbus parameters	96
Firmware	
Reboot the device	33
Reset device to factory settings	33
First steps	41
Function	10

G

Gateway	
Reading device information	59
Reading status and diagnostic information.....	59
Resetting, rebooting and localising the device	58
Setting the application tag.....	61
Updating the firmware	60
General	7
General functions.....	41
GET request	37

I

ifm IoT Core	35, 111
Info	
Show device information	33
Inputs	92
Inputs / outputs	91
Install ESI file	79
Integrate the IO-Link master into the TwinCAT project.....	79
Intended use	9
Interfaces	92
Internet of Things (IoT)	11
IO-Link	11
IO-Link Acyclic Command (0x3100).....	100
IO-Link devices	
Accessing parameters.....	56
Indicating IO-Link events.....	58
Reading a writing device information.....	58
IO-Link Inputs (0x6000)	101
IO-Link Outputs (0x7000)	101
IO-Link ports	16
Activate data transfer to LR AGENT or LR SMARTOBSERVER	30
Configure operating mode.....	31
Configuring data transfer to LR AGENT or LR SMARTOBSERVER.....	53

Configuring device validation and data storage	51
Indicating port events	56
Reading / writing process data	53
Set the device validation and data storage	32
Setting the operating mode of pin 4 (US)	50
IO-Link Ports (Class A)	22
IO-Link supply	12
IoT	
Configure IP settings	26
Configure security mode	27
Configure the interface to LR AGENT or LR SMARTOBSERVER	29
Configuring access rights	28, 46
Configuring IP settings	46
Configuring security mode	47
IoT Core	
Diagnostic codes	40
General information	36
IoT port	21
IT security	8
L	
LED indicators	20
Legal and copyright information	5
LR DEVICE	25
M	
Maintenance, repair and disposal	87
Managing notifications	73
Manufacturer Specific Index (0x2000)	99
Mapping	
Device Status (0xF100)	105
Diagnosis Message	109
Port Qualifier (0xF101)	106
MDP Standard Information (0x1000)	98
Mechanical data	93
Mount the device	13
Mounting	13
MQTT support	68
N	
Note	98
Connection states	69
Security mode	47
Notes	14
O	
Offline parameter setting	26
Operating and display elements	19
Operating conditions	93
Operation	86
Outputs	92
Overview	19
IoT profile	112
IoT services	120
IoT types	119
P	
Parameter data	96
Parameter setting	12
Port Configuration (0x8000)	102
Port Mode (0x9000)	103
POST request	38
Preliminary note	5
Principle of the acyclic command processing	85
Process Data Objects (PDO)	97
Profile	
blob	112
deviceinfo	113
devicetag	113
iolinkdevice_full	114
iolinkmaster	114
mqttCmdChannel	115
mqttCmdChannelSetup	115
mqttConnection	115
mqttSetup	116
network	116
parameter	117
processdata	117
runcontrol	117
service	117
software	117
software/uploadedablessoftware	118
Timer	118
Programmers' notes	36
Purpose of the document	5
R	
Read and write cyclic process data	81
Read diagnostic and status information	82
Read IO-Link events	82
Reading and writing process data	77
Remarks	26
Replacing IO-Link device	87
Required background knowledge	7
S	
Safety instructions	7
Safety symbols on the device	7
Searching for elements in the device tree	75
Security mode	11
Service	
factoryreset	120
getblobdata	121
getdata	121
getdatamulti	122
getelementinfo	122
getsubscriberlist	124
getsubscriptioninfo	125
gettree	126
install	127
iolreadacyclic	127
iolwriteacyclic	127
querytree	128
reboot	128
Reset	128
setblock	129
setdata	130
signal	130
start	131
start_stream_set	131
stop	131
stream_set	132
subscribe	132
unsubscribe	134
validation_useconnecteddevice	134
ServiceID	
getidentity	123

Setting the storage duration	45
Set-up	23
Status LEDs.....	20
Subscribing to notifications.....	62

T

Technical data	91
----------------------	----

U

Updating the firmware	78, 87
Use acyclic services	84
Use ADS over EtherCAT	84
Use CANopen over EtherCAT.....	84
Using the IoT-Core Visualizer.....	72
Using Web Socket.....	66
Using web-based management.....	86

V

Visual indication.....	12
Voltage supply	21