

# Specifications

Atlas Copco Pressure Transducer  
Standard parts  
Quick and simple installation

Atlas Copco Pressure Transducer

Air compressor pressure transducer, the output signal of the package and standard stainless steel housing. Chip using special imported materials, high-stability pressure transducer r assembly, highly reliable amplification circuitry and temperature compensation, better performance.

pressure transducer specification:

span: 0~1~150(MPa)

Comprehensive Accuracy : 0.1%FS,0.2%FS,0.5%FS,1.0%FS

Current: 4~20mA(two cable),0~5V,1~5V,0~10V(three cable)

Voltage: 24DCV(9~36DCV)

Medium Temperature: -20~150°C

Temperature: (-20~85°C)





No.	Part No.	Description
1	1089057471	Atlas Copco Temperature Sensor
2	1089057553	Atlas Copco Pressure Sensor
3	1089057556	Atlas Copco Pressure Sensor
4	1089063716	Atlas Copco Temperature Switch
5	1089057540	Atlas Copco Pressure Sensor
6	1089057412	Atlas Copco Ambient Temperature Sensor
7	1089063713	Atlas Copco Temperature switch
8	1089957980	Atlas Copco Pressure Sensor

- 9 1089957954 Atlas Copco Pressure Sensor
- 10 1089957660 Atlas Copco Pressure Sensor
- 11 1089962535 Atlas Copco Pressure Sensor
- 12 1089057514 Atlas Copco Pressure Sensor
- 13 1089057512 Atlas Copco Pressure Sensor
- 14 1089962532 Atlas Copco Pressure Sensor
- 15 1089962534 Atlas Copco Pressure Sensor
- 16 1089962537 Atlas Copco Pressure Sensor
- 17 88H359 Atlas Copco Pressure Transducer
- 18 1089057511 Atlas Copco Pressure Transducer
- 19 1089057541 Atlas Copco Pressure Transducer
- 20 1089057551 Atlas Copco Pressure Transducer
- 21 1089057533 Atlas Copco Pressure Transducer

## 22 1089057573 Atlas Copco Pressure Transducer

- 23 1089057565 Atlas Copco Pressure Transducer
- 24 1089057535 Atlas Copco Pressure Transducer
- 25 1089057574 Atlas Copco Pressure Transducer
- 26 1089057564 Atlas Copco Pressure Transducer
- 27 1089057528 Atlas Copco Pressure Transducer
- 28 1089057578 Atlas Copco Pressure Transducer
- 29 1089057520 Atlas Copco Pressure Transducer
- 30 1089057510 Atlas Copco Pressure Transducer
- 31 1089962501 Atlas Copco Pressure Transducer
- 32 1089057543 Atlas Copco Pressure Transducer
- 33 1089962533 Atlas Copco Pressure Transducer
- 34 1089962536 Atlas Copco Pressure Transducer
- 35 1089057530 Atlas Copco Pressure Transducer
- 36 1089057404 Atlas Copco Temperature Sensor
- 37 1089057407 Atlas Copco Temperature Sensor
- 38 1089057445 Atlas Copco Temperature Sensor
- 39 1089057449 Atlas Copco Temperature Sensor

40	1089057455	Atlas Copco Temperature Sensor
41	1089057473	Atlas Copco Temperature Sensor
42	1089057470	Atlas Copco Temperature Sensor
43	1089067470	Atlas Copco Temperature Sensor
44	1089057444	Atlas Copco Temperature Sensor
45	1089057464	Atlas Copco Temperature Sensor
46	1089057401	Atlas Copco Temperature Sensor
47	1089057402	Atlas Copco Temperature Sensor
48	1089057403	Atlas Copco Temperature Sensor
49	1089057405	Atlas Copco Temperature Sensor
50	1089057406	Atlas Copco Temperature Sensor
51	1089057408	Atlas Copco Temperature Sensor
52	1089057441	Atlas Copco Temperature Sensor
53	1089057440	Atlas Copco Temperature Sensor
54	1089057416	Atlas Copco Temperature Sensor
55	1089962512	Atlas Copco Pressure Sensor
56	1089057545	Atlas Copco Pressure Sensor
57	1089957955	Atlas Copco Pressure Sensor
58	1089957960	Atlas Copco Pressure Sensor
59	1089962513	Atlas Copco Pressure Transducer
60	1089962514	Atlas Copco Pressure Transducer
61	1089962518	Atlas Copco Pressure Sensor
62	1089958001	Atlas Copco Temperature Sensor
63	92688597	Ingersoll Rand Temperature Sensor
64	39875539	Ingersoll Rand Pressure Sensor
65	39877618	Ingersoll Rand Pressure Sensor
66	39929435	Ingersoll Rand Pressure Sensor
67	39853791	Ingersoll Rand Pressure Sensor
68	39853809	Ingersoll Rand Pressure Sensor
69	42852483	Ingersoll Rand Pressure Sensor
70	39560628	Ingersoll Rand Temperature Sensor
71	37952355	Ingersoll Rand Temperature Sensor

72	39921705	Ingersoll Rand Temperature Sensor
73	39538079	Ingersoll Rand Temperature Sensor
74	392716109	Ingersoll Rand Temperature Sensor
75	38433546	Ingersoll Rand Temperature Sensor
76	85652535	Ingersoll Rand Temperature Sensor
77	42853243	Ingersoll Rand Temperature Sensor
78	37952439	Ingersoll Rand Temperature Sensor
79	39438536	Ingersoll Rand Temperature Switch
80	37952264	Ingersoll Rand Temperature Switch
81	39419668	Ingersoll Rand Temperature Switch
82	37952264	Ingersoll Rand Temperature Switch
83	39428305	Ingersoll Rand Temperature Switch
84	39416128	Ingersoll Rand Temperature Switch
85	39413307	Ingersoll Rand Temperature Switch
86	37952421	Ingersoll Rand Temperature Switch
87	250039-910	Sullair Pressure Sensor
88	250039-909	Sullair Temperature Sensor
89	02250058-087	Sullair Temperature Sensor
90	A100003136	Comp Air Pressure Sensor
91	100001684	Comp Air Pressure Sensor
92	11507074	Comp Air Pressure Sensor
93	11190974	Comp Air Pressure Sensor
94	A98612-120	Comp Air Pressure Sensor
95	98612-122	Comp Air Pressure Sensor
96	A11507074	Comp Air Pressure Sensor
97	09Q060G1936	Comp Air Temperature Sensor
98	100003018	Comp Air Temperature Sensor
99	100002946	Comp Air Temperature Sensor
100	A10630674	Comp Air Temperature Sensor
101	A03740577	Comp Air Temperature Sensor
102	100010275	Comp Air Temperature Sensor
103	98612-126	Comp Air Temperature Sensor

104 635007901 Boge Pressure Sensor

105 639002803 Boge Temperature Sensor